


Ohagan



15min



(D) Montageanleitung

(NL) Handleiding voor de montage

(TR) Montaj talimati

(F) Notice de montage

(CZ) Montážní návod

(GB) Assembly instructions

(HU) Szerelési útmutató




(PL) Instrukcja montażu

(RU) Инструкция по монтажу


(IT) Istruzioni di montaggio

(SK) Návod na montáž


(RO) Instrucțiuni de montaj




x1




x1




x3






x8






x8




0-6






II



III







Service • Assistenza • Dienstverlening • Serwis •
 Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam •
 Nazwa • Jméno • Názov • Név •
 Denumire • Isim • Название


Ohagan

Nr • No. • N° • Номер • Č • Sz

Type • Tipo • Tipus • Typ •
 Тип • Тір




A




X...

B




X...

C



X...

D



X...

E



X...