

Passend für die folgenden Modelle:

<b>Marke</b>	<b>Typennummer</b>	<b>Modell</b>
Krups	KP510510/7Z0	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510510/7Z1	ESPRESSO CIRCOLO FLOW STOP
Krups	KP5105TH/7Z1	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510810/7Z1	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510T65/7Z1	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510565/7Z1	ESPRESSO CIRCOLO FLOW STOP
Krups	KP5108TH/7Z1	ESPRESSO CIRCOLO FLOW STOP
Krups	KP500010/7Z2	ESPRESSO DOLCE GUSTO
Krups	KP500210/7Z2	ESPRESSO DOLCE GUSTO
Krups	KP510T10/7Z1	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510T10/7Z0	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510531/7Z0	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510565/7Z0	ESPRESSO CIRCOLO FLOW STOP
Krups	KP5105TH/7Z0	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510810/7Z0	ESPRESSO CIRCOLO FLOW STOP
Krups	KP5108TH/7Z0	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510910/7Z0	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510T31/7Z0	ESPRESSO CIRCOLO FLOW STOP
Krups	KP510T65/7Z0	ESPRESSO CIRCOLO FLOW STOP
Krups	KP5010E2/7Z1	ESPRESSO DOLCE GUSTO CIRCOLO
Krups	KP500010/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500010/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500025/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500025/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500040/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500040/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP5000CH/7Z0	ESPRESSO DOLCE GUSTO APOLLO

Krups	KP5000CH/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP5000E2/7Z1	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP5000MS/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500210/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500210/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500225/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500225/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500240/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500240/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500250/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500250/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP5002CH/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP5002CH/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP5002E2/7Z1	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP5002MS/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500610/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500610/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500625/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500625/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500640/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500640/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500650/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP500650/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP5006CH/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP5006CH/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP5006E2/7Z1	ESPRESSO DOLCE GUSTO APOLLO
Krups	KP5006MS/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP500910/7Z0	ESPRESSO DOLCE GUSTO
Krups	KP500910/7Z1	ESPRESSO DOLCE GUSTO

Krups	KP500950/7Z0	ESPRESSO DOLCE GUSTO
Krups	KP500950/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP5009E2/7Z0	ESPRESSO DOLCE GUSTO
Krups	KP5009E2/7Z1	ESPRESSO DOLCE GUSTO
Krups	KP501010/7Z1	ESPRESSO DOLCE GUSTO CIRCOLO
Krups	KP501040/7Z1	ESPRESSO DOLCE GUSTO
Moulinex	PV5010AR/7Z1	ESPRESSO DOLCE GUSTO CIRCOLO
Moulinex	PV5000AR/7Z1	ESPRESSO DOLCE GUSTO
Moulinex	PV5006AR/7Z1	ESPRESSO DOLCE GUSTO
Krups	PJ5000B1/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	PJ5000B2/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	PJ5002B1/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	PJ5002B2/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	PJ5006B1/7Z0	ESPRESSO DOLCE GUSTO APOLLO
Krups	PJ5006B2/7Z0	ESPRESSO DOLCE GUSTO APOLLO
T-fal	PK510T50/7Z0	ESPRESSO CIRCOLO FLOW STOP
T-fal	PK501050/7Z1	ESPRESSO DOLCE GUSTO CIRCOLO
Arno	PJ510555/7Z1	ESPRESSO CIRCOLO FLOW STOP
Arno	PJ510554/7Z1	ESPRESSO CIRCOLO FLOW STOP
Arno	PJ510554/7Z0	ESPRESSO CIRCOLO FLOW STOP
Arno	PJ510555/7Z0	ESPRESSO CIRCOLO FLOW STOP
Arno	PJ5000B1/7Z1	ESPRESSO DOLCE GUSTO
Arno	PJ5000B2/7Z1	ESPRESSO DOLCE GUSTO
Arno	PJ5002B1/7Z1	ESPRESSO DOLCE GUSTO
Arno	PJ5002B2/7Z1	ESPRESSO DOLCE GUSTO
Arno	PJ5006B1/7Z1	ESPRESSO DOLCE GUSTO
Arno	PJ5006B2/7Z1	ESPRESSO DOLCE GUSTO