

**Passend für die folgenden Modelle:**

Balay	3GIB3110/01	
Balay	3KE280IA/01	
Balay	3KE280IA/02	
Balay	3GI150B/03	
Balay	GILBLC5EE/41	
Balay	GILBLF2EE/41	
Balay	3GI151B/41	
Balay	3GI150B/42	
Balay	3FI5671B/02	
Balay	3FI5671B/01	
Balay	3GI150B/41	
Balay	3GI151B/43	
Balay	3GI151B/42	
BOSCH	KIM28442IE/04	
BOSCH	KIM28472IE/02	
BOSCH	KIE28441FF/04	
BOSCH	KIE28470IE/03	
BOSCH	KIM26443GB/03	
BOSCH	KIE28470IE/07	
BOSCH	KIM28472FF/04	
BOSCH	KIM28472IE/01	
BOSCH	KIM28442IE/03	
BOSCH	KIE28441IE/01	
BOSCH	KIE28470IE/02	
BOSCH	GFL10441/02	
BOSCH	KIE28441FF/03	
BOSCH	GIL12472/03	
BOSCH	GIL12472/01	
BOSCH	KIE28470IE/05	
BOSCH	GFL12441/01	
BOSCH	KIE28471/02	
BOSCH	GIL10441/01	
BOSCH	KIM28442IE/01	
BOSCH	GFL12442/01	
BOSCH	KIE28471/03	
BOSCH	KIM28442IE/02	
BOSCH	KIE28471/04	
BOSCH	KIE28441/02	
BOSCH	KIE28441/01	
BOSCH	KIE28471/05	
BOSCH	GIL10471/01	
BOSCH	KIM28472FF/02	
BOSCH	GFL10441/01	
BOSCH	KIM28472FF/01	
BOSCH	KIE28441FF/05	
BOSCH	KIE28441FF/02	

BOSCH	KIM26443GB/01	
BOSCH	KIM26443GB/02	
BOSCH	KIE28471/01	
BOSCH	KIM28472FF/03	
BOSCH	KIE28441FF/01	
BOSCH	GID14A40/01	
BOSCH	GIL12472/02	
BOSCH	KIE28470IE/04	
BOSCH	GIL10441/02	
BOSCH	GIL10471/02	
BOSCH	GIL12441/01	
BOSCH	GIL12443GB/01	
BOSCH	GIL12442/01	
BOSCH	GIL12471/01	
BOSCH	GID18A40GB/02	
BOSCH	GFD14A40/01	
BOSCH	GID14A00/01	
BOSCH	GID18A40GB/01	
BOSCH	GID18A40/01	
BOSCH	GFD18A40/01	
BOSCH	GID18A00/01	
BOSCH	GIL1174GB/41	
BOSCH	KIM26470GB/01	
BOSCH	GIL1240/42	
BOSCH	KIM26470GB/02	
BOSCH	GFL1240/43	
BOSCH	GIL10440/02	
BOSCH	GIL1240CH/42	
BOSCH	GIL1174GB/42	
BOSCH	GIL1240/43	
BOSCH	GIL1174/42	
BOSCH	GIL1140/42	
BOSCH	GIL10470/02	
BOSCH	KIM28440/01	
BOSCH	GFL1240/41	
BOSCH	GFL1040/42	
BOSCH	KIM28441/02	
BOSCH	KIM28440/02	
BOSCH	KIM28441/01	
BOSCH	KIM26440GB/01	
BOSCH	KIM26471GB/01	
BOSCH	GIL1274/41	
BOSCH	GIL1240GB/42	
BOSCH	GFL1040/41	
BOSCH	GIL1040/41	
BOSCH	KIM28440IE/01	
BOSCH	GIL1040GB/41	
BOSCH	GIL1040CH/41	

BOSCH	KIM28441E/01	
BOSCH	GIL1074NE/41	
BOSCH	KIM27474E/01	
BOSCH	GIL1074/41	
BOSCH	GIL11473GB/01	
BOSCH	GIL1140/41	
BOSCH	GIL10440/01	
BOSCH	GIL1174/41	
BOSCH	GIL10470/01	
BOSCH	GIL1240CH/41	
BOSCH	GIL1240/41	
BOSCH	GIL1240GB/41	
BOSCH	GIL1240GB/43	
BOSCH	GIL1274/42	
BOSCH	GIL1274/43	
BOSCH	KIM27474E/02	
BOSCH	KIM27475/01	
BOSCH	KIM28470/01	
BOSCH	KIM27475E/01	
BOSCH	KIM27475E/02	
BOSCH	KIM27475E/03	
BOSCH	KIM28440E/02	
BOSCH	KIM28441E/02	
BOSCH	KIM27470FF/02	
BOSCH	KIM25473GB/01	
BOSCH	KIM25473GB/02	
BOSCH	KIM25473GB/03	
BOSCH	KIE28470/02	
BOSCH	KIE28440E/02	
BOSCH	KIE28440/01	
BOSCH	KIE28440E/01	
BOSCH	KIE28440/02	
BOSCH	KIE28470/01	
Constructa	CE71240/41	
Constructa	CE31240/43	
Constructa	CE61240/42	
Constructa	CE61241/01	
Constructa	CE71240/42	
Constructa	CE61241/02	
Constructa	CE61240/41	
Constructa	CE31240/41	
De Dietrich	GILDDC1FF/41	GG6105E10
De Dietrich	GILDDE1FF/42	GG6135E10
De Dietrich	GILDDE1FF/43	
GAGGENAU	GILGGF3/41	IG421110
GAGGENAU	GILGGF3/42	IG421110
GAGGENAU	IC191220/01	
GAGGENAU	IC191220/02	

GAGGENAU	GILGGC2/41	IG411-109
Junker&Ruh	G11JR40/42	
Junker&Ruh	G11JR440/01	
Junker&Ruh	G11JR40/41	
Küppersbusch	GILKBC6/01	IT109-5
Küppersbusch	GILKBC6/03	IT109-5
Küppersbusch	GILKBC6/02	IT109-5
Küppersbusch	GILKBF6/42	ITE129-4
Küppersbusch	GILKBF6/41	ITE129-4
Küppersbusch	GILKBF6/43	ITE129-4
Küppersbusch	GILKBC5/41	ITE109-4
Küppersbusch	GILKBF7/01	
Miele	F524I	F 524 i
Miele	F524I-1	F 524 i-1
Miele	F513I	F 513 i
Miele	F524AI	F 524 Ai
Miele	F524AI-1	F 524 Ai-1
Miele	F524E	F 524 E
Miele	F524E-1	F 524 E-1
NEFF	K4445X4FF/04	
NEFF	K4434X4FF/01	
NEFF	K4254X4GB/03	
NEFF	K4445X4FF/01	
NEFF	G1614X4/02	
NEFF	K4434X4FF/04	
NEFF	K4254X4GB/01	
NEFF	K4445X4FF/02	
NEFF	G1614X4/01	
NEFF	K4444X4/01	
NEFF	G5624X5/01	
NEFF	G3614X5/01	
NEFF	G1624X5/02	
NEFF	G3614X4/01	
NEFF	K4444X4/02	
NEFF	K4254X4GB/02	
NEFF	K4445X4FF/03	
NEFF	K4434X4FF/03	
NEFF	G3614X4/02	
NEFF	K4444X4/03	
NEFF	K4434X4FF/02	
NEFF	G1624X5/01	
NEFF	G5614X4/01	
NEFF	K4444X4/05	
NEFF	K4445X4FF/05	
NEFF	G3624X5/01	
NEFF	G1624X5/03	
NEFF	G5614X4/02	
NEFF	G5624X4GB/01	

NEFF	G5624X4/01	
NEFF	G1624X4/01	
NEFF	G3624X0/41	GD120
NEFF	K4255X1GB/01	
NEFF	G5624X0/41	GI125
NEFF	K4255X3GB/01	
NEFF	G5614X0GB/42	G5614
NEFF	G5614X1/02	GI105
NEFF	G1614X0/41	
NEFF	G3624X0/43	GD120
NEFF	G1624X0/41	GI121
NEFF	K4455X1IE/02	
NEFF	G5614X0/41	GI105
NEFF	G5624X0GB/41	G5624
NEFF	G1624X0/42	GI121
NEFF	G5614X0GB/41	G5614
NEFF	K4455X1IE/01	
NEFF	G5624X0GB/43	G5624
NEFF	G5614X1/01	GI105
NEFF	G1624X0/43	GI121
NEFF	G5624X0/43	GI125
NEFF	K4204X4GB/02	
NEFF	G1524X4GB/01	
NEFF	K4435X2IE/02	
NEFF	K4205X1GB/01	
NEFF	K4435X2IE/01	
NEFF	K4204X4GB/01	
NEFF	K4204X4GB/03	
NEFF	K4205X3GB/01	
NEFF	K4205X3GB/02	
NEFF	G1524X0GB/41	
NEFF	K4400X0/01	Geräte-/Blenden-Farbe weiß
NEFF	K4435X2/01	
NEFF	K4400X0/02	Geräte-/Blenden-Farbe weiß
NEFF	K4425X1/01	
NEFF	K4425X2IE/01	
NEFF	G1524X0GB/42	
NEFF	G1524X4GB/02	
SIEMENS	GI14DA40/01	
SIEMENS	GI18DA40GB/01	
SIEMENS	GI14DA00/01	
SIEMENS	GF14DA40/01	
SIEMENS	GI18DA40GB/02	
SIEMENS	GI18DA00/01	
SIEMENS	GF18DA40/01	
SIEMENS	GI18DA40/01	
SIEMENS	GI10B470/03	
SIEMENS	KI26M443GB/03	

SIEMENS	KI28E470IE/04	
SIEMENS	KI28E440/01	
SIEMENS	KI28E441FF/03	
SIEMENS	KI28E440/02	
SIEMENS	KI28E440/03	
SIEMENS	KI28E470/05	
SIEMENS	KI28E440/05	
SIEMENS	KI28M441IE/04	
SIEMENS	KI28M472FF/02	
SIEMENS	KI28E470/04	
SIEMENS	KI28M472FF/01	
SIEMENS	KI26M441GB/01	
SIEMENS	KI26M443GB/02	
SIEMENS	KI28E470/01	
SIEMENS	KI26M443GB/01	
SIEMENS	GF12B40/42	
SIEMENS	KI28E470IE/03	
SIEMENS	GF10B40/41	
SIEMENS	KI28M441IE/01	
SIEMENS	KI28M440IE/02	
SIEMENS	KI28M441IE/03	
SIEMENS	KI28M442IE/03	
SIEMENS	KI28M441IE/02	
SIEMENS	KI28M442IE/02	
SIEMENS	G110B74/41	
SIEMENS	G110B40/41	
SIEMENS	G112B40/42	
SIEMENS	G110B74NE/41	
SIEMENS	KI28M440IE/01	
SIEMENS	G112B40/41	
SIEMENS	KI28E470/03	
SIEMENS	G112B40GB/42	
SIEMENS	G112B40GB/41	
SIEMENS	G112B440/41	
SIEMENS	G112B440/01	
SIEMENS	G112B74/41	
SIEMENS	KI28M442IE/05	
SIEMENS	KI28M470/01	
SIEMENS	GF10B40/42	
SIEMENS	GF12B40/43	
SIEMENS	KI28M472IE/02	
SIEMENS	GF12B40/41	
SIEMENS	G110B470/02	
SIEMENS	G110B440/02	
SIEMENS	KI28M472FF/04	
SIEMENS	KI28E470/02	
SIEMENS	KI28M472IE/01	
SIEMENS	KI28E470IE/02	

SIEMENS	KI28E470IE/05	
SIEMENS	KI28E440/07	
SIEMENS	KI28M472FF/03	
SIEMENS	KI28E441FF/05	
SIEMENS	KI28E440/04	
SIEMENS	KI28M441/03	
SIEMENS	KI28E441FF/04	
SIEMENS	KI28M441/04	
SIEMENS	KI28E440/06	
SIEMENS	KI28M441/01	
SIEMENS	KI28E440IE/02	
SIEMENS	KI28M441/02	
SIEMENS	KI28E440IE/01	
SIEMENS	KI28E441FF/01	
SIEMENS	KI28E440IE/03	
SIEMENS	KI28M442IE/04	
SIEMENS	KI28E441FF/02	
SIEMENS	KI28E470/06	
SIEMENS	GF10B40/03	
SIEMENS	GI10B440/01	
SIEMENS	KI28M440/01	
SIEMENS	GI10B470/01	
SIEMENS	KI28M440/02	
SIEMENS	GI10B440/03	
SIEMENS	GI12B74/42	
SIEMENS	KI28E470IE/06	
SIEMENS	GI12B74/43	
SIEMENS	KI27M471IE/02	
SIEMENS	GI11B74GB/41	
SIEMENS	GI12B40GB/43	
SIEMENS	KI27M471IE/01	
SIEMENS	GI11B74/42	
SIEMENS	GI11B40/42	
SIEMENS	GI11B40/41	
SIEMENS	GI11B74/41	
SIEMENS	KI27M475/02	
SIEMENS	KI27M475/01	
SIEMENS	GI12B40/43	
SIEMENS	KI27M470IE/02	
SIEMENS	KI27M471IE/03	
SIEMENS	KI27M470IE/01	