

Passend für die folgenden Modelle:

Marke	Typennummer	Modell
Philips	HD8751/11	Intelia
Philips	HD8750/13	Intuita
Philips	HD8753/95	Intelia Evo
Philips	HD8753/83	Intelia
Philips	HD8752/85	Intelia Evo
Philips	HD8755/02	Intelia Evo
Philips	HD8750/11	Intuita
Philips	HD8755/01	Intelia Evo
Philips	HD8760/09	Minuto
Philips	HD8760/01	Minuto
Philips	HD8745/23	Xsmall Class
Philips	HD8852/01	Energica
Philips	HD8855/01	Exprelia Evo
Philips	HD8857/01	Exprelia Evo
Philips	HD8773/47	Minuto
Philips	HD8778/11	Moltio
Philips	HD8772/47	Moltio Focus class
Philips	HD8768/09	Moltio
Philips	HD8768/08	Moltio
Philips	HD8769/11	Moltio
Philips	HD8768/03	Moltio
Philips	HD8768/43	Moltio
Philips	HD8769/43	Moltio
Philips	HD8768/05	Moltio
Philips	HD8769/19	Moltio
Philips	HD8762/01	Minuto Focus class
Philips	HD8766/01	Moltio

Philips	HD8769/89	Moltio
Philips	HD8763/01	Minuto Cappuccino schwarz
Philips	HD8761/01	Minuto Focus
Philips	HD8766/09	Moltio
Philips	HD8769/09	Moltio
Philips	HD8767/01	Moltio
Philips	HD8769/01	Moltio
Philips	HD8768/01	Moltio
Philips	HD8769/18	Moltio
Philips	HD8766/04	Moltio
Philips	HD8769/08	Moltio
Philips	HD8743/13	Xsmall
Philips	HD8745/11	Xsmall Class
Philips	HD8743/19	Xsmall
Philips	HD8743/11	Xsmall
Philips	HD8747/02	Xsmall Chrome
Philips	HD8745/06	Xsmall Class
Philips	HD8745/22	Xsmall Class
Philips	HD8745/03	Xsmall Class
Philips	HD8743/03	Xsmall
Philips	HD8747/09	Xsmall Chrome
Philips	HD8745/04	Xsmall Class
Philips	HD8743/17	Xsmall
Philips	HD8745/19	Xsmall Class
Philips	HD8743/16	Xsmall
Philips	HD8747/01	Xsmall Chrome
Philips	HD8745/05	Xsmall Class
Philips	HD8743/12	Xsmall
Philips	HD8743/15	Xsmall

Philips	HD8747/03	Xsmall Chrome
Philips	HD8745/01	Xsmall Class
Philips	HD8753/04	Intelia
Philips	HD8753/96	Intelia Evo
Saeco	SUP021D	Incanto
Saeco	SUP021YBDR	Incanto
Saeco	SUP021YOR	Incanto
Saeco	SUP031OR	ODEAGIRO
Saeco	SUP030ND	Primea Cappuccino Ring
Saeco	SUP038Z	Xelsis
Saeco	SUP032NR	Talea Ring
Saeco	RI9836/41	Syntia
Saeco	SUP031O	Odea Go
Saeco	RI9837/41	Syntia
Saeco	SUP030BD	Primea Cappuccino Touch New Edition
Saeco	SUP030UDR	Primea Cappuccino Duo New Edition
Saeco	SUP021YDS	Incanto
Saeco	SUP030ADR	Primea Touch Plus
Saeco	SUP032BR	Talea Ring Plus
Saeco	RI9833/47	Syntia
Saeco	SUP032OR	Talea Giro
Saeco	SUP038	Xelsis
Saeco	SUP037DR	Syntia SNT6720SS / SNT5720WH
Saeco	SUP033R	Xsmall
Saeco	RI9829/11	Saeco Talea Black Touch Plus
Saeco	RI9826/11	Talea Black Ring Plus
Saeco	RI9833/41	Syntia
Saeco	SUP021YNR	Incanto
Saeco	RI9757/01	Odea

Saeco	SUP037DRJ	Syntia
Saeco	SUP032AR	Talea Touch
Saeco	HD8833/11	Syntia Nachtschwarz
Saeco	HD8836/11	Syntia Schwarz
Saeco	HD8836/21	Syntia Wei?
Saeco	HD8837/01	Syntia Edelstahl
Saeco	HD8837/31	Syntia Edelstahl rot
Saeco	HD8838/01	Syntia Cappuccino
Saeco	HD8854/01	Exprelia Schwarz
Saeco	SUP021NR	Incanto
Saeco	HD8856/01	Exprelia Edelstahl
Saeco	HD8943/11	Xelsis Schwarz
Saeco	HD8943/21	Xelsis Wei?
Saeco	HD8943/29	Xelsis Wei?
Saeco	HD8944/01	Xelsis Edelstahl
Saeco	HD8944/47	Xelsis Edelstahl
Saeco	HD8946/01	Xelsis Digital ID
Saeco	HD8953/09	Xelsis Evo
Saeco	HD8953/11	Xelsis Evo
Saeco	HD8953/19	Xelsis Evo
Saeco	SUP021YD	Incanto
Saeco	HD8954/09	Xelsis Evo
Saeco	HD8954/47	Xelsis Evo
Saeco	RI93084/01	Platinum Vision
Saeco	RI9752/11	Odea Black Go
Saeco	SUP021YE	Incanto
Saeco	SUP021YO	Incanto
Saeco	SUP021YS	Incanto
Saeco	SUP021YADR	Incanto

Spidem	SUP035	My Coffee
--------	--------	-----------