

Sehr geehrte Damen und Herren

Bitte schauen Sie sich das Video zum Zusammenbau des Motorrades bei YouTube an. Das ist oftmals hilfreicher als eine Bedienungsanleitung.

YouTube: Teil 1: [https://www.youtube.com/watch?v=dEQlrH\\_Dfm4&t=26s](https://www.youtube.com/watch?v=dEQlrH_Dfm4&t=26s)

Teil 2: <https://www.youtube.com/watch?v=BV43h7QsSMo>

**Diesen Teil bitte schon beim Zusammenbau ausführen.**

Den schwarzen Kabelschuh bitte gleich mit einer Flachzange etwas fester drücken, damit dieser erst gar nicht herunterrutschen kann.

**Falls doch einmal ein Problem auftritt:**

Fehlerbehebung: Motorrad Groß (Top Racer)

**Meistens sind es nur Kleinigkeiten, die sehr schnell und einfach behoben werden können.**

Was genau funktioniert nicht?

- 1: Licht? (Sicherung Prüfen) Sitz abheben.
- 2: Lässt sich nicht aufladen? (Sicherung Prüfen) Sitz abheben.
- 3: Fährt nicht? (Sicherung Prüfen/Kabel am Schalter Prüfen)

Mit einem Schlitz Schraubendreher den Silbernen Deckel (Fahrtrichtung Schalter (Modell Top Racer)) herausheben.

Den schwarzen Kabelschuh richtig herum (Kabelschuhe dürfen keinen Kontakt untereinander bekommen) wieder aufstecken.

Dabei bitte gleich mit einer Flachzange etwas fester drücken.

Mit freundlichen Grüßen

Eurostock

Dear Sir or Madam,

Please watch the video on assembling the motorcycle on YouTube. This is often more helpful than an instruction manual.

YouTube:

Part 1: [https://www.youtube.com/watch?v=dEQlrH\\_Dfm4&t=26s](https://www.youtube.com/watch?v=dEQlrH_Dfm4&t=26s)

Part 2: <https://www.youtube.com/watch?v=BV43h7QsSMo>

**Please perform this step during assembly.**

Use flat pliers to tighten the black cable lug so that it does not slip off in the first place.

**If a problem should occur:**

Troubleshooting: Large Motorcycle (Top Racer)

**Most of the time, it's just small things that can be fixed quickly and easily.**

What exactly is not working?

- 1: Light? (Check fuse) Lift the seat.
- 2: Won't charge? (Check fuse) Lift the seat.
- 3: Won't drive? (Check fuse/Check cable on switch)

Use a flathead screwdriver to lift the silver cover (direction switch (Top Racer model)).

Reattach the black cable lug in the correct orientation (cable lugs must not come into contact with each other).

Please use flat pliers to tighten it at the same time.

Kind regards,

Eurostock