

Passend fuer folgende Modelle:

| Marke | Typennummer | Modell |
|--------------|--------------------|---------------|
| Balay | 3FIB3620/04 | |
| Balay | 3FIB3620/05 | |
| Balay | 3FIB3720/04 | |
| Balay | 3FIB3720/02 | |
| Balay | 3FIB3720/03 | |
| Balay | 3FIB3620/03 | |
| Constructa | CK66543/02 | |
| Constructa | CK66544/03 | |
| Constructa | CK66544/02 | |
| Constructa | CK66543/01 | |
| Constructa | CK66544/01 | |
| Constructa | CK66530/01 | |
| Balay | KI4BYQ6/01 | |
| Balay | 3FIB3610/01 | |
| Balay | KI4BYQ5/01 | |
| Balay | KI4BYQ7/01 | |
| Balay | 3FIB3710/02 | |
| Balay | 3FIB3610/02 | |
| Balay | KI4BYQ5/02 | |
| Balay | 3FIB3710/01 | |
| Bosch | KID26V00FF/01 | |
| Bosch | KID28A21IE/01 | |
| Bosch | KID28A30/01 | |
| Bosch | KID28A21/02 | |
| Bosch | KID28A21/01 | |
| Bosch | KID26A30/01 | |
| Bosch | KID28A20IE/01 | |

| | | |
|-------|---------------|--|
| Bosch | KID28A21IE/03 | |
| Bosch | KID28V20FF/03 | |
| Bosch | KID28V20FF/01 | |
| Bosch | KID28V01FF/01 | |
| Bosch | KID26V00FF/02 | |
| Bosch | KID28A21/03 | |
| Bosch | KID26V21IE/03 | |
| Bosch | KID26V21IE/05 | |
| Bosch | KID26A21/01 | |
| Bosch | KID28V00FF/01 | |
| Bosch | KID26V21IE/07 | |
| Bosch | KID26V21IE/04 | |
| Bosch | KID28A20/01 | |
| Bosch | KID26A21/03 | |
| Bosch | KID26A20/01 | |
| Bosch | KID28V20FF/02 | |
| Bosch | KID26V20IE/01 | |
| Bosch | KID26V21IE/01 | |
| Bosch | KID28V20FF/05 | |
| Bosch | KID26V21IE/02 | |
| Bosch | KID26V01FF/01 | |
| Bosch | KID26V21IE/06 | |
| Bosch | KID28V20FF/04 | |
| Bosch | KID28X30/01 | |
| Bosch | KID28V00FF/02 | |
| Bosch | KID28V20FF/06 | |
| Bosch | KID28A21IE/02 | |
| Bosch | KID26A21/02 | |
| Bosch | KID26A21/04 | |

| | | |
|------------|---------------|--|
| Junker&Ruh | JC60TB20/03 | |
| Junker&Ruh | JC60TB20/01 | |
| Junker&Ruh | JC60TB20/02 | |
| Junker&Ruh | JC60TB30/01 | |
| SIEMENS | KI28DA00FF/03 | |
| SIEMENS | KI28DA20/01 | |
| SIEMENS | KI26DA20/04 | |
| SIEMENS | KI28DA20/02 | |
| SIEMENS | KI28DA20CH/03 | |
| SIEMENS | KI28DA20IE/02 | |
| SIEMENS | KI28DA00FF/01 | |
| SIEMENS | KI26DA20/06 | |
| SIEMENS | KI28DA20IE/03 | |
| SIEMENS | KI28DA20CH/02 | |
| SIEMENS | KI26DA00FF/01 | |
| SIEMENS | KI28DA20IE/01 | |
| SIEMENS | KI28DA20/05 | |
| SIEMENS | KI26DA00FF/02 | |
| SIEMENS | KI26DA20FF/02 | |
| SIEMENS | KI26DA30/01 | |
| SIEMENS | KI26DA20/03 | |
| SIEMENS | KI28DA20IE/04 | |
| SIEMENS | KI26DA20/01 | |
| SIEMENS | KI28DA20/04 | |
| SIEMENS | KI26DA20/05 | |
| SIEMENS | KI28DA30/01 | |
| SIEMENS | KI28DA20IE/05 | |
| SIEMENS | KI26DA20FF/01 | |
| SIEMENS | KI26DA20FF/03 | |

| | | |
|---------|---------------|--|
| SIEMENS | KI28DA20/03 | |
| SIEMENS | KI28DA20CH/01 | |
| SIEMENS | KI28DA00FF/02 | |
| SIEMENS | KI26DA00FF/03 | |
| SIEMENS | KI26DA20/02 | |
| Siemens | KI26DA30/02 | |
| Bosch | KID26A30/02 | |
| Bosch | KID28V20FF/07 | |
| Bosch | KID28V20FF/08 | |
| Bosch | KID26V21IE/08 | |
| Bosch | KID26V21IE/09 | |