

Passend für die folgenden Modelle:

Electrolux	372273	RK6200BW
Gorenje	340108	R6150BW
Gorenje	444966	RB6150BX
Gorenje	444932	RB6152BX
Gorenje	370312	RB6150BX
Gorenje	320840	RB6151BW
Gorenje	340109	RB6151BW
Gorenje	444883	RB6152BW
Gorenje	370314	R6150BX
Gorenje	352066	RB6152BX
Gorenje	444753	RB6151BW
Gorenje	336392	RB6152BW
Gorenje	444967	R6150BX
Gorenje	315957	RK6181AW
Gorenje	444973	RK6200BW
Gorenje	320836	RC67A1/2
Gorenje	444977	RK61810W
Gorenje	340118	RK6160AW
Gorenje	327038	NRK6181CW
Gorenje	335557	RK61821X
Gorenje	335498	NRK6181CX
Gorenje	384695	RK62010W/2
Gorenje	399648	RK61832X
Gorenje	373864	NRK6181CW
Gorenje	329198	NRK6181CX
Gorenje	335556	RK61811X
Gorenje	445027	NRK61801W

Gorenje	331918	RK6201BX
Gorenje	331919	NRK6201DX
Gorenje	444863	RK6162AX
Gorenje	339331	NRK6181GX
Gorenje	332018	RK6180AW
Gorenje	331922	NRK6181CX
Gorenje	315978	NRC66C1
Gorenje	329195	NRK6181CB
Gorenje	331921	RK6181AX
Gorenje	410915	K7000I
Gorenje	445049	RK62010X/2
Gorenje	445048	RK62010W/2
Gorenje	381564	NRK61811W
Gorenje	335551	RK61810W
Gorenje	381565	NRK61811X
Gorenje	445058	RK1800W
Gorenje	445057	RK1800X
Gorenje	445067	RK61832W
Gorenje	445066	RK61832X
Gorenje	445029	NRK61811W
Gorenje	445028	NRK61801X
Gorenje	445030	NRK61811X
Gorenje	409705	K7000SW
Gorenje	384696	RK62010X/2
Gorenje	381512	NRK61801W
Gorenje	335552	RK61820W
Gorenje	381513	NRK61801X
Gorenje	335553	RK61811W
Gorenje	335554	RK61821W

Gorenje	335492	RK6162AW
Gorenje	373862	RK6181AW
Gorenje	415762	K7000SW
Gorenje	415763	K7000I
Gorenje	444979	RK6181AW
Gorenje	367450	RK6181BW
Gorenje	367455	RK6182BX
Gorenje	335493	RK6162AX
Gorenje	335496	RK6182AW/2
Gorenje	335497	NRK6181CW
Gorenje	373692	RK61810W
Gorenje	442409	RK61811XPL
Gorenje	444872	RK61820W
Gorenje	340046	RK61620W
Gorenje	444871	RK61810W
Gorenje	335121	RK6202BX
Gorenje	444874	RK61821W
Gorenje	335124	RK6202BW
Gorenje	444873	RK61811W
Gorenje	444876	RK61821X
Gorenje	444875	RK61811X
Gorenje	444877	RK6182AX
Gorenje	444921	RK61620X
Gorenje	320838	RC66A1
Gorenje	320834	RK60398HW-N1
Gorenje	364924	NRK6201DW
Gorenje	444856	RK6202BX
Gorenje	444857	RK6202BW
Gorenje	340114	RK6181AX/2

Gorenje	340116	RK6160AX
Gorenje	444833	RK6201BX
Gorenje	439682	RK6161AX
Gorenje	399650	RK61832W
Gorenje	444836	NRK6181CX
Gorenje	444834	NRK6201DX
Gorenje	444781	NRK6181CW
Gorenje	444812	NRK6181CB
Gorenje	444813	NRK6181CX
Gorenje	336372	RK6182AW
Gorenje	336373	RK6182AX
Gorenje	336374	RK6182AW/2
Gorenje	336375	RK6182AX/2
Gorenje	389907	RK1800W
Gorenje	398038	RKV61811W
Gorenje	444742	NRK6181CW
Gorenje	389906	RK1800X
Gorenje	444749	RK6181AW/2
Gorenje	444748	RK6201BW
Gorenje	444751	RK6161AW
Gorenje	345878	RK61620X
Gorenje	370321	NRK6180CX
Gorenje	370320	NRK6180CW
Gorenje	379678	NRK6180CW-1
Gorenje	379675	NRK6180GW
Gorenje	379676	NRK6180GX
Gorenje	444916	RF6171BW
Gorenje	444907	RK6181AX/2
Gorenje	444908	RK6160AX

Gorenje	444909	RK6160AW
Gorenje	444902	RK61620W
Gorenje	315980	R6181AW
Gorenje	320837	RF60308HW-N1
Gorenje	320839	R60318HW-N1
Gorenje	320851	RF65B1
Gorenje	327036	R6151BW
Gorenje	327040	R6181AW
Gorenje	327041	R6181AX
Gorenje	331923	R6181AX
Gorenje	335491	R6152BW
Gorenje	336377	R6182AW
Gorenje	336378	R6182AX
Gorenje	340106	R6181EX
Gorenje	340107	R6181BW
Gorenje	340120	RF6171AX
Gorenje	343140	R6181EW
Gorenje	344061	R6151BX
Gorenje	344105	RF6171BW
Gorenje	351848	RF6173AX
Gorenje	353556	R6181AX
Gorenje	353560	R6181AW
Gorenje	364900	R6181AW
Gorenje	367384	R6181BX
Gorenje	367425	RF6171BX
Gorenje	367446	RF6172BW
Gorenje	367449	RF6172BX
Gorenje	370316	R6180AW
Gorenje	370317	R6180AX

Gorenje	370318	RF6150BX
Gorenje	373861	RF6171AW
Gorenje	373863	R6181BW
Gorenje	376018	RK6181EW
Gorenje	376019	RK6181EX
Gorenje	376032	NRK6181GW
Gorenje	376033	NRK6181GX
Gorenje	379726	RK6200FW
Gorenje	379727	RK6200FX
Gorenje	379728	NRK6200HW
Gorenje	382422	NRK6182GX
Gorenje	382423	RK6182EW
Gorenje	382424	RK6182EX
Gorenje	382815	R6181AX
Gorenje	384410	R6181AW
Gorenje	384412	R6181AX
Gorenje	387497	NRK6201HX
Gorenje	387885	R6152BRD
Gorenje	387886	R6180AX
Gorenje	387889	R6180AW
Gorenje	398080	RKV6200FW
Gorenje	405005	R6181AB
Gorenje	412348	R6180AX
Gorenje	412351	R6180AW
Gorenje	414131	NRK61W2
Gorenje	414132	RK61W2
Gorenje	418853	R6151BX
Gorenje	419020	R6152BX
Gorenje	419022	R6152BC

Gorenje	419024	R6152BR
Gorenje	431439	R6181AX
Gorenje	437451	R6181AW
Gorenje	444743	R6181AW
Gorenje	444750	RF6171AW
Gorenje	444752	R6151BW
Gorenje	444754	RF6151BW
Gorenje	444779	R6151BW
Gorenje	444782	R6181AW
Gorenje	444783	R6181AX
Gorenje	444837	R6181AX
Marke	Typennummer	Modell
Gorenje	444878	R6182AW
Gorenje	444879	R6182AX
Gorenje	444936	R6181AX
Gorenje	444937	R6181AW
Gorenje	444959	R6181BX
Gorenje	444960	RF6171BX
Gorenje	444961	RF6172BW
Gorenje	444962	RF6172BX
Gorenje	444968	R6180AW
Gorenje	444969	R6180AX
Gorenje	444970	RF6150BX
Gorenje	444978	RF6171AW
Gorenje	444980	R6181BW
Gorenje	445016	RK6200FW
Gorenje	445017	RK6200FX
Gorenje	445032	RK6182EW
Gorenje	445033	RK6182EX

Gorenje	445038	R6181AX
Gorenje	445043	R6181AW
Gorenje	445044	R6181AX
Gorenje	445054	R6152BRD
Gorenje	445083	R6181AB