






# WALKER OTL-2SR






PZ2

















**1**












**2**







 <b>A</b> x2	 <b>B</b> x4	 <b>C</b> x6	 <b>D</b> x8	 <b>E</b> x12	 <b>F</b> x6
			 <b>G</b> x1	 <b>H</b> x4	 <b>I</b> x4

Service – Dienstverlening – Serwis – Servis – Сервисная служба – Assistenza - Szerviz Тип – Type – Tip – Тип – Tipus - Tipo	
<b>A</b>	
<b>B</b>	
<b>C</b>	
<b>D</b>	
<b>E</b>	
<b>F</b>	
<b>G</b>	
<b>H</b>	
<b>I</b>	