

Passend für die folgenden Modelle:

<b>Marke</b>	<b>Typennummer</b>	<b>Modell</b>
Bosch	MUM48A06/07	
Bosch	MUM48A06/08	
Bosch	MUM4856EU/05	MUM4410
Bosch	MUM4880/07	
Bosch	MUM48140DE/07	
Bosch	MUM4757COE/05	collection
Bosch	MUM4780/06	ProfiMixx 47 microtronic
Bosch	MUM4780/05	ProfiMixx 47 microtronic
Bosch	MUM4780/07	ProfiMixx 47 microtronic
Bosch	MUM4656COE/03	collection
Bosch	MUM48140DE/05	
Bosch	MUM4880/05	
Bosch	MUM4856EU/08	
Bosch	MUM46R1/03	electronic
Bosch	MUM47A1/03	microtronic
Bosch	MUM44K1/03	
Bosch	MUM4427/04	
Bosch	MUM47A1/05	microtronic
Bosch	MUM48R1GB/05	
Bosch	MUM47A1/04	microtronic
Bosch	MUM46R1/04	electronic
Bosch	MUM48R1/05	Kunststoffrührschüssel
Bosch	MUM48W1/05	
Bosch	MUM48W11/08	
Bosch	MUM4427/06	
Bosch	MUM48A1/05	
Bosch	MUM4427/05	

Bosch	MUM4835/05	
Bosch	MUM46A1GB/05	
Bosch	MUM46R1/05	electronic
Bosch	MUM4428/06	
Bosch	MUM46A1GB/04	MUM4400
Bosch	MUM4427/03	
Bosch	MUM4427/08	
Bosch	MUM48W11/07	
Bosch	MUM48R1GB/08	
Bosch	MUM48R1/08	
Bosch	MUM48W1/08	ProfiMixx 47 microtronic
Bosch	MUM4428/08	
Bosch	MUM48A1/08	
Bosch	MUM46A1GB/08	
Bosch	MUM48W1/07	
Bosch	MUM46A1GB/07	Serie Ralf Zacherl (jaune-chef)
Bosch	MUM48A1/07	
Bosch	MUM48R1/07	
Bosch	MUM4856/08	
Bosch	MUM4835/07	
Bosch	MUM4428/07	
Bosch	MUM48R1GB/07	MUM4430
Bosch	MUM4427/07	
Bosch	MUM4607/03	cereaLine
Bosch	MUM4607/02	cereaLine
Bosch	MUM4607/01	cereaLine
Bosch	MUM4807GB/05	
Bosch	MUM4807GB/08	
Bosch	MUM4415TW/08	

Bosch	MUM48140DE/08	
Bosch	MUM48SL/08	
Bosch	MUM4415JP/01	
Bosch	MUM48A11/05	
Bosch	MUM4415TW/01	
Bosch	MUM48SL/05	
Bosch	MUM4880/08	
Bosch	MUM4630/03	electronic
Bosch	MUM4856EU/07	