



- | | | | |
|---|-----------------------------|---|-------------------------|
| Ⓚ | Montageanleitung | Ⓒ | Assembly instructions |
| Ⓛ | Notice de montage | Ⓜ | Istruzioni di montaggio |
| Ⓝ | Handleiding voor de montage | Ⓟ | Instrukcja montażu |
| Ⓒ | Montážní návod | Ⓢ | Návod na montáž |
| Ⓜ | Szerelési utmutató | Ⓡ | Instrucțiuni de montaj |
| Ⓣ | Montaj talimatı | Ⓡ | Инструкция по монтажу |

Ausgabe: 202205010




0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180
190
200


Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба		
Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Isim • Название	ELB	
Nr. • No. • N° • Номер • Č • Sz	9790 7626	
Typ • Type • Tip • Típus • Tipo Тип	YS-ET6729	





A	M6X12MM X16	B	X1	C	M4X15MM X16	D	X4
----------	----------------	----------	----	----------	----------------	----------	----




1


A	M6X12MM
	X16

B		X1
----------	-------------------------------------------------------------------------------------	----






2

C	M4X15MM
	X8




3

C	M4X15MM	D	
	X8		X4



4



5

