



70086567, 87787852, 67027356, 36549560, 82096857,
19737167, 45374613, 37434304, 21814766, 46708317,
Art. Nr. 87446628, 65692808, 72115010, 30972767, 75247360

Gondola (3)



- | | | | |
|------|-----------------------------|------|-------------------------|
| (D) | Montageanleitung | (GB) | Assembly instructions |
| (FR) | Notice de montage | (IT) | Istruzioni di montaggio |
| (NL) | Handleiding voor de montage | (PL) | Instrukcja montażu |
| (CZ) | Montážní návod | (SK) | Návod na montáž |
| (HU) | Szerelési útmutató | (RO) | Instrucțiuni de montaj |
| (TR) | Montaj talimati | (RU) | Инструкция по монтажу |



110 kg-MAX



LKZ 41507

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба





Name • Nom • Nome • Naam • Nazwa • Jméno • Název • Név • Denumire • İsim • Название Gondola (3)

Nr. • No. • N° • Номер • Č • Sz 70086567, 87787852, 67027356, 36549560, 82096857, 19737167, 45374613, 37434304, 21814766, 46708317

Typ • Type • Típ • Típus • Tipo • Тип



1



2

