




















Gregory











- PL Instrukcja montażu
- D Aufbauanleitung
- GB Assembly instruction
- SK Návod na montáž









- Karta gwarancyjna
der Garantieschein
- Guarantee certificate
- Záručný list





| | | | | |
|--|--|--|--|---|
| A  x1 | B  x28 | C  x22 | D  x22 | F  x6 |
| Š  x6 | S  x18 | D1  x8 | W1 3,5x16  x60 | |
| O  O1 O2 O3 O4 x5 | | | | |









A=B

