

Warning Instructions and Safety Information for the 70x70CM Glass Plate - Black

1. Usage Instructions:

- This glass plate is designed for use as a protective cover for fireplace areas, stove tops, or as a decorative table surface. It is also suitable for use on chest of drawers or sideboards as a stylish and functional surface.
- When using the glass as a floor plate in front of a fireplace, ensure it is placed on a flat, stable surface to prevent slipping or tipping.

2. Handling and Installation:

- **Handle with care:** Although the glass is made of tempered safety glass (ESG), it is still vulnerable to impact. Handle the glass plate carefully to avoid accidental dropping or sudden impacts that could cause cracking or shattering.
- **Proper placement:** Make sure the glass is installed in a secure location where it will not be subject to any undue force or weight, especially when used as a tabletop or stove cover.
- **Installation on stove or fireplace:** If using the glass as a stove or fireplace cover, ensure that it is placed directly over the surface without any gaps to prevent accidental contact with hot surfaces.

3. Safety Considerations:

- **Spark and heat protection:** While the glass provides reliable protection from sparks, embers, and ash when used in front of a fireplace, it is important not to rely on it as the only source of fire protection. Always exercise caution when handling hot materials.
- **Temperature limitations:** The glass plate is temperature-resistant, but extreme direct heat exposure (e.g., direct contact with flames) may cause damage. Avoid placing extremely hot objects directly onto the glass surface to prevent thermal shock.
- **Edge protection:** The glass edges are polished, but be mindful of the edges to avoid injury. If the glass is broken, handle the fragments carefully and dispose of them properly.

4. Cleaning and Maintenance:

- **Regular cleaning:** Clean the glass regularly to maintain its appearance and functionality. Use a soft cloth and a mild cleaning solution to avoid scratching the surface. Abrasive cleaning materials or harsh chemicals should be avoided.
- **No harsh chemicals:** Do not use chemicals that could damage or discolor the glass. A simple glass cleaner or a diluted solution of mild dish soap and water will suffice.
- **Drying:** After cleaning, dry the surface with a clean, soft cloth to avoid water marks or streaks.

5. Storage and Protection:

- **Proper storage:** If not in use, store the glass plate in a safe location where it will not be exposed to impacts or temperature extremes. Use padded materials to protect the glass when storing or transporting it.
- **Avoid heavy pressure:** Do not place heavy objects on top of the glass plate when not in use, as excessive weight can lead to cracking or distortion.

6. General Warnings:

- **Glass breakage:** While the glass is made of durable, toughened safety glass, it can still break under extreme conditions. Always check for any cracks or chips before use and replace the glass if damaged.
- **Children and pets:** Keep children and pets away from the glass plate when in use to prevent accidental injury.

By following these safety and care instructions, you can ensure the longevity and safety of your 70x70CM glass plate and enjoy its aesthetic and protective benefits.