

INSTRUCTION MANUAL



MB-EL

HOW TO SET TIME:

- 1 Pull out the crown for a click, Set the hands by turning the crown in either direction to the desired hour and minute time.
- 2 Push the crown to the normal position to start.

HOW TO USE EL BUTTON:

- 1 Press the EL Button, The backlight of the watch will be on.
- 2 The backlight of the this watch use an electro-luminescent (EL)light.
- 3 Frequent use of the backlight shortens the EL battery life.

HOW TO USE BEZEL:

Rotate the mark on bezel counterclockwise to the minute hand position before diving, the marker can remind diver the start diving time and minute hands points to how many minutes he has dived.

HOW TO REPLACE BATTERY FOR EL:

At the first sign of low power (no light or dim display) have the battery replaced by our authorized distributor.

- 1 Opening the case back, You will see the CR2016 battery for EL.
Remove the contact spring pressed on the battery and take out the dead battery.
- 2 Place the new battery and screw spring tightly. E1 brightness should be the original situation.
- 3 Close case back

HOW TO REPLACE MOVEMENT BATTERY:

- 1 Following the step (1) replacing EL battery, take out CR2016.
- 2 Remove the insulator on the movement, You will see movement battery SR626SW. Take out the dead battery.
- 3 Place new battery and install CR2016 BAT, Close case back.
- 4 Adjust the hand at the correct time.

NOTE:Avoid short circuit or exposing the battery in fire.

TO PRESERVE THE QUALITY OF YOUR WATCH:

- 1 As this watch contains precise electronic components, It Is suggested that the back cover be removed only by authorized person
- 2 Do not operate pushers when the watch is wet or in water.
- 3 If the watch is used in water, Or it is wet, Wipe it thoroughly dry.
- 4 Should water or coidensation appear in the watch, Immediately open the case back and leave it air dry because water can corrode eletronic parts inside the case.
- 5 Although the watch is designed to withstand shocks under normal use, It is inadequate to subject it to rough impact.
- 6 Clean the watch with a soft cloth or water. Never use chemical solution.
- 7 Avoid exposure the watch to chemicals such as gasoline, Aero spray, Paints Etc, Whose chemical action will damage watch.
- 8 Avoid wearing the watch in electro magnetic condition, or put watch under strong light for too long.