

DC311XX  
DC313XX

05 Contents 05 Inhalt 05 Contenu 05 Inhoud 05 Sisältö  
 06 Indhold 06 Contenido 06 Contento 06 Conteúdo  
 06 Περιεχόμενα 06 Innehåll




x1



x1



x1



x1



x2



x2


CR2032




x2



x1




05 Getting started 05 Erste Schritte 05 Démarrage 05 Aan de slag 05 Aloitussopas 05 Kom i gang  
 06 Operazioni preliminari 06 Para empezar 06 Para começar 06 Πρώτα βήματα 06 Kom igång




✓




✓



✗




✗




x1





x1




4x AA/LR6




30mm





x1





x1




CR2032




15mm






**DE** Optional features **DE** Optionale Funktionen  
**FR** Options disponibles **FR** Opções **FR** Valinnaiset ominaisuudet  
**OK** Valgírnie funktíoner **IT** Funzionalità opzionali  
**ES** Opciones disponibles **PT** Funcções opcionais  
**GR** Προαιρετικές λειτουργίες πρόσθετων **SE** Möjliga funktioner



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	•	•					•	•
	•	•	•	•			•	•
	•	•	•	•	•	•	•	•



**SE** Linking **DE** Einlernen **FR** Programmation  
**UK** Verknüpfung **FI** Linkittäminen **OK** Forbinde  
**IT** Collegamento **ES** Enlace  
**PT** Programação **GR** Ουδέωση **SE** Länkning



**GB** Trouble shooting **DE** Fehlerbehebung **FR** Dépannage **UK** Probleemoplossing  
**FI** Vianmääritys **OK** Problemløsning **IT** Risoluzione die problemi **ES** Solución de  
 problemas **PT** Resolução de problemas **GR** Αντιμετώπιση προβλημάτων **SE** Felsökning

**livewell.honeywell.com**

