


# HAITI III (2AL-MaxiRC)



- |                                  |                                |
|----------------------------------|--------------------------------|
| (DE) Montageanleitung            | (IT) Istruzioni di montaggio   |
| (PL) Instrukcja montażu          | (FR) Notice de montage         |
| (NL) Handleiding voor de montage | (RO) Instrucțiuni de asamblare |
| (GB) Assembly instructions       | (SK) Montážny návod            |
| (TR) Montaj talimatı             | (CZ) Montážní návod            |
| (RU) Инструкция по монтажу       | (HU) Szerelési útmutató        |





Service - Servis - Dienstverlening - Servis - Serwis - Сервисная служба - Servizio  
 Service - Serviciu - Služby - Szolgáltatás

Name - Nazwa - Naam - Name - Isim - название  
 Nome - Nom - Numele - Meno - Jméno - Neve





HAITI III (2AL-MaxiRC)

F1 H-130  x5	F2 H-130  x4	S1  x30	U1  x30	T1  x4	P1 55x55  x5	P2 45x45  x2
-----------------------	-----------------------	---------------	---------------	--------------	-----------------------	-----------------------





2AL



F1	H-130	F2	H-130	S1	U1	T1
x2		x2		x12	x12	x2

MaxIRC



F1	H-130	F2	H-130	S1	U1	T1
x3		x2		x18	x18	x2