

Passend für die folgenden Modelle:

Marke	Typennummer	Modell
Saeco	SUP031OR	ODEAGIRO
Saeco	RI9751/01	Odea
Saeco	SUP031O	Odea Go
Saeco	RI9754/15	Odea
Saeco	RI9754/43	Odea
Saeco	RI9754/02	Odea
Saeco	RI9753/47	Odea
Saeco	RI9754/41	Odea
Saeco	RI9754/01	Odea
Saeco	RI9755/21	Odea
Saeco	RI9753/97	Odea
Saeco	RI9755/97	Odea
Saeco	RI9757/03	Odea
Saeco	RI9754/22	Odea
Saeco	RI9755/22	Odea
Saeco	RI9755/47	Odea
Saeco	RI9752/47	Odea
Saeco	RI9757/01	Odea
Saeco	RI9752/97	Odea
Saeco	RI9757/11	Odea
Saeco	RI9752/11	Odea Black Go
Saeco	RI9754/47	Odea
Saeco	RI9757/47	Odea
Saeco	RI9754/21	Odea
Saeco	RI9752/48	Odea