


<b>D</b> Montageanleitung	<b>GB</b> Assembly instructions	<b>NL</b> Handleiding voor de montage	<b>PL</b> Instrukcja montażu	<b>HU</b> Szerelési útmutató	<b>RO</b> Instrucțiuni de montaj
<b>FR</b> Notice de montage	<b>IT</b> Istruzioni di montaggio	<b>CZ</b> Montážní návod	<b>SK</b> Návod na montáž	<b>TR</b> Montaj talimatı	<b>RU</b> Инструкция по монтажу



A5	0mm	4x
b3	KA37	4x
c	6,3x11	4x
e11	24,3	8x
f8	Auszug 246	2x
n	8x30mm	12x
s6	4x27	2x
v	Leim	1x
y4	Leim	1x



**Service • Assistenza • Dienstverlening • Servis**  
**Servis • Szerviz • Сервисная служба**

Marka - Brand - Marke - Marca - Брэнд	MZ
Modell - Model - Model - Modelo - Модель	
Art. No. - № - Nummer - Číslo - Szám	
Type - Type - Typ - Tipo - Тип	4.8114

101.	ASL 986x370x15mm	1
21.	ASR 986x370x15mm	1
31.	BL 700x370x15mm	1
41.	BD 700x370x15mm	1
51.	ZB 669x354x15mm	1
6.	TR 766x346x15/16mm	2
7.	BLE 699x55x15/16mm	1
8.	SKV 696x189x15/16mm	1
9.	SKB 645x318x3mm	1
10.	SZL 322x128x12mm	1
11.	SZH 635x128x12mm	1
12.	SZR 322x128x12mm	1
13.	RW 998x681x3mm	1



A5	0mm	4x	l	4x	4x
b3	KA37	4x	n	8x30mm	20x
c	6,3x11	4x	q10	M4x9	2x x8
e11	24,3	8x	s6	4x27	12x y4
f1		8x	t1	3,5x15	2x y14
f8	Auszug 246	2x	t6	3,5x30	8x z
h4	Stopfen 8=5mm	4x	v		3x z6
					Sk-Verstärkung 320 1x

