


Art. No. 31919111, 62867949, 37601139, 21061355, 32484764, 39228009, 49500958, 96141741, 96678147, 41468805, 84082537, 78910231, 88819336, 32980444, 92434833, 92280936, 24328761, 74261214

HENRY

u shape



D Montageanleitung

FR Notice de montage

NL Handleiding voor de montage

CZ Montážní návod

HU Szerelési útmutató

TR Montaj talimatı

GB Assembly instructions


IT Istruzioni di montaggio

PL Instrukcja montażu

SK Návod na montáž

RO Instrucțiuni de montaj

RU Инструкция по монтажу



630 kg-Max

LKZ 40937










**Service • Usługa • Обслуживание • Servizio • Un service
Serviciu • Služba • Servis • Szolgáltatás**

Name • Nom • Nome • Naam
• Nazwa • Název • Názov
• Név • Nume • Isim
• Название


HENRY

• Nr • No • N° • Номер • C • Sz

31919111, 62867949, 37601139, 21061355, 32484764, 39228009, 49500958,
96141741, 96678147, 41468805, 84082537, 78910231, 88819336, 32980444,
92434833, 92280936, 24328761, 74261214



1



2

