






















ASSEMBLY INSTRUCTIONS












SKU:WF286457AAW
SKU:WF286458AAW



Part List


A	B	C	D	E	F	G	H	J	K
									
76PCS	76PCS	8PCS	4PCS	74PCS	8PCS	6PCS	20PCS	1PC	2PCS

①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩
									
1PC	1PC	1PC	1PC	1PC	1PC	1PC	1PC	1PC	2PCS


⑪	⑫	⑬	⑭	⑮	⑯	⑰	⑱	⑲	⑳	㉑
										
1PC	1PC	1PC	2PCS	2PCS	3PCS	1PC	4PCS	4PCS	4PCS	4PCS

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6



STEP 7




STEP 8




ASSEMBLY INSTRUCTIONS


STEP 9




STEP 10




STEP 11




STEP 12



STEP 13




STEP 14




ASSEMBLY INSTRUCTIONS


STEP 15




STEP 16




STEP 17




STEP 18




STEP 19




STEP 20



STEP 21




STEP 22




ASSEMBLY INSTRUCTIONS

STEP 23





STEP 24





STEP 25

* 2




STEP 26




STEP 27

* 4









STEP 28

* 4




ASSEMBLY INSTRUCTIONS




ASSEMBLY INSTRUCTIONS

STEP 35



STEP 36



STEP 37

