

Passend für die folgenden Modelle:

Tefal	GC701840/79A	OptiGrill GC701
Tefal	GC702D16/79A	OptiGrill GC702 Typ 8350 Serie 1
Tefal	GC750D16/79A	OptiGrill Elite
Tefal	GC716D12/79A	OptiGrill+
Tefal	GC722D16/79A	OPTIGRILL+ XL TYPE 8360 SERIES 1
Tefal	GC730D12/79B	OptiGrill Smart
Tefal	GC702D01/79A	OptiGrill
Tefal	GC702D16/79B	OptiGrill GC702
Tefal	GC750D12/79A	OptiGrill Elite GC750D
Tefal	GC712D12/79B	OptiGrill
Tefal	GC712812/79B	OptiGrill+ Snacking & Baking
Tefal	GC714812/79B	OptiGrill+ Snacking & Baking
Tefal	GC705D16/79A	OptiGrill Standard Edelstahl
Tefal	GC702861/79A	OptiGrill
Tefal	GC712D61/79A	OptiGrill+
Tefal	GC712D34/79A	OptiGrill
Tefal	GC704453/79A	OptiGrill
Tefal	GC712D54/79A	OptiGrill
Tefal	GC704553/79A	OptiGrill
Tefal	GC703D66/79A	OptiGrill
Tefal	GC712834/79B	OptiGrill+
Tefal	GC712D53/79A	OptiGrill
Tefal	GC702D25/79A	OPTIGRILL TYPE 8350 SERIE 1
Tefal	GC712D26/79A	OptiGrill
Tefal	GC702D54/79A	OptiGrill
Tefal	GC712D61/79B	OptiGrill+
Tefal	GC706D12/79A	OptiGrill Inox 5 Levels
Tefal	GC704D54/79A	OptiGrill
Tefal	GC702D61/79A	OptiGrill
Tefal	GC704E53/79A	OptiGrill
Tefal	GC706D34/79A	OptiGrill Inox 5 Levels
Tefal	GC712D28/79A	OptiGrill+ INOX
Tefal	GC712D34/79B	OptiGrill
Tefal	GC702DTL/79A	OptiGrill
Tefal	GC712812/79B	OptiGrill+ Snacking & Baking
Tefal	GC702D26/79A	OptiGrill
Tefal	GC712812/79A	OptiGrill+ Snacking & Baking
Tefal	GC701D40/79A	OptiGrill
Tefal	GC712D28/79B	OptiGrill+ INOX
Tefal	GC702853/79A	OptiGrill
Tefal	GC702D34/79A	OptiGrill
Tefal	GC702861/79B	OptiGrill
Tefal	GC702D53/79A	OptiGrill
Tefal	GC702D70/79A	OptiGrill
Tefal	GC712D26/79B	OptiGrill
Tefal	GC702D53/79B	OptiGrill

Tefal	GC712834/79A	OptiGrill+
Tefal	GC712D12/79A	OptiGrill
Tefal	GC701840/79A	OptiGrill
Tefal	GC702853/79B	OptiGrill
Tefal	GC712D54/79B	OptiGrill
Tefal	GC704853/79A	OptiGrill
Tefal	GC702D52/79A	ActiGrill
Tefal	GC714834/79B	OptiGrill+ Snacking & Baking
Tefal	GC713D40/79A	OptiGrill
Tefal	GC714812/79A	OptiGrill+ Snacking & Baking
Tefal	GC713D40/79A	OptiGrill
Tefal	GC713D40/79B	OptiGrill
Tefal	GC714834/79A	OptiGrill+ Snacking & Baking
Tefal	GC714D66/79A	OptiGrill+ Snacking & Baking
Tefal	GC730D12/79A	OptiGrill Smart
Tefal	GC716812/79A	OptiGrill+ WAFFLES PLATES
Tefal	GC714D66/79B	OptiGrill+ Snacking & Baking
Tefal	GC715D40/79A	OptiGrill+ Snacking & Baking
Tefal	GC715D40/79B	OptiGrill+ Snacking & Baking
Tefal	GC730D34/79A	OptiGrill Smart
Tefal	GC715D28/79A	OptiGrill+ Snacking & Baking
Tefal	GC730D53/79A	OptiGrill
Tefal	GC730D53/79B	OptiGrill
Rowenta	GR712D21/79A	OptiGrill
Rowenta	GR702D21/79B	OptiGrill
Rowenta	GR712D21/79B	OptiGrill
Rowenta	GR702D21/79A	OptiGrill
OBH Nordica	GO702DS0/79A	OptiGrill
OBH Nordica	GO7148S0/79A	OptiGrill+ Snacking & Baking
OBH Nordica	GO712DS0/79B	OptiGrill
OBH Nordica	GO706D15/79A	OptiGrill Inox 5 Levels
OBH Nordica	GO712DS0/79A	OptiGrill
OBH Nordica	GO702DS0/79B	OptiGrill
OBH Nordica	GO7148S0/79B	OptiGrill+ Snacking & Baking
KRUPS	MG705D51/79A	Precision Grill
All-Clad	PG710850/79A	Contact Grill
All-Clad	PG721000/79A	Contact Grill Electric Autosense
All-Clad	PG720051/79A	Contact Grill OptiGrill