SAFETY INSTRUCTION

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference

- The luminaires may only be installed by authorized and qualified technicians according the valid regulations for electrical installation.
- Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture can come into contact with any areas of the terminal connections or voltage control parts.
- The electrical supply must be switched off at the outset, preferably by means of a switch in the distribution box, before any installation, maintenance or repair work is undertaken.
- Exterior lighting must not be installed during rain.
- 5. Take account of the minimal separation distance from other objects and the room required around the fitting.
- If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- Clamping screws in electrical connections must be adequately tightened. This is particularly the case with 12V low voltage conductors.
- Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components
- 9. Take account of all available technical information.
- 10. Meaning of symbols:

ΙΡΧΧ	This icon indicates the level of water-proof and dust-proof
\bigcirc	Protection Class I: the fitting must be earthed
	Protection Class II: the fitting is doubled insulated and does not require earthing
	Protection Class III: the fitting is low voltage
(]ª.5n₽	Minimum distance from lighted objects (meters)
Hav.#Streem GUI0 2mg.55W	The type of lamp and maximum size and wattage indicated in each lighting unit must not be exceed; different items require different kind of light sources with different bulb icons
220-240V- 50Hz	The armature is designed to work only with the indicated voltage. Different items require different working voltage.
0	The luminaire can be used in combination with a dimmer
R	The luminaire can be dimmed by wall switch
Light Angle	The reference light angle and light space of the luminaire
Ĩ	🐼 👒 🖸
Thisle	uminaire cannot be disposed together with normal domestic waste in standard


rubbish can, but you have to bring it to a staging area for electrical waste

11. Take note of the symbols when connecting wires:

		(DE)	(GB)	(FR)	(NL)	(PL)	(NO)	(DK)
	L	Stromführender Leiter	Live-conductor	Conducteur	Spanning- voerencie draad	Proewool prodowy	Strømførende leder	Strømførende leder
0.02.01	٢	Schultzleiter	Earth conductor	Conducteur de protection (cerre)	Aardkabel	Przewód uziemiający	Jordledningen	Jordledningen
LON	N	Neutralleiter	Neutral conductor	Conducteur neubre	Nulleider	Proswód zerowy	Nøytralleder	Neutrallader
		(SE)	(H)	(IT)	(ES)	(CZ)	(PT)	(GR)
	L	Strömförande. Jedare	Virtajohdin	Conduitore soito tensione	Conductor de. corriente	Vodič pod napětím	Condutor vivo	Ρευματοφόρος αγωγός
ĬĬ	٢	Skyddsledare	Suojajohdin	Conductore di terra	Conductor de protección	Ochranný vodič	Condutor de terra	Αγωγός γείωσης
	N	Neutralledare	Nollajohdin	Conduttore neutro	Conductor neutro	Neutrální vodič	Condutor neutro	Ουδέτερος αγωγός

FittinQ LTD 55 Boker Street, London, W1U 7EU United Kingdom





FittinQ B.V. Smaragdweg 52, 5527 LB Hapert, The Netherlands www.gazgo.nl FittinQ LTD 55 Baker Street, London, W1U 7EU United Kingdom **QAZQA**