






- | | | | |
|---|-----------------------------|---|-------------------------|
| Ⓛ | Montageanleitung | Ⓒ | Assembly instructions |
| Ⓧ | Notice de montage | Ⓡ | Istruzioni di montaggio |
| Ⓝ | Handleiding voor de montage | Ⓟ | Instrukcja montażu |
| Ⓒ | Montážní návod | Ⓢ | Návod na montáž |
| ⓗ | Szerelési utmutató | Ⓡ | Instrucțiuni de montaj |
| Ⓣ | Montaj talimatı | Ⓡ | Инструкция по монтажу |

Ausgabe:20230611













Service • Assistenza • Dienstverlening • Serwis
 Servis • Szerviz • Сервисная служба®

| | |
|---|-----------|
| Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Isim • Название | |
| Nr. • No. • N° • Номер • Č • Sz | 5202 3021 |
| Typ • Type • Tip • Típus • Tipo Тип | YS-WR7097 |






X 2

| | | | | |
|--|---|---|--|--|
| A M4X12MM  X4 | B D15  X42 | C  X42 | D D12  X8 | E  X8 |
| F M4X25MM  X8 | G M4X40MM  X16 | H  X1 | J  X4 | |




1




2

B D15
X2




3

B D15
X8




4

B D15
X18






5

B D15
X14






6

| | | | |
|---|---------|---|----|
| A | M4X12MM | H | |
|  | X4 |  | X1 |







7

| | | | |
|---|----|---|---------|
| J | | G | M4X40MM |
|  | X4 |  | X14 |




8

| | | | |
|---|-----|---|---------|
| D | D12 | E | M4X25MM |
|  | X8 |  | X8 |
| | |  | X8 |



X 2



9

