

Passend für die folgenden Modelle:

Marke	Typennummer	Modell
Bosch	BCH6ATH25/01	Athlet 25,2V
Bosch	BCH6ATH25K/02	Athlet 25,2V
Bosch	BCH6ATH25K/01	Athlet 25,2V
Bosch	BCH6ATH25/02	Athlet 25,2V
Bosch	BBH625W60/01	Athlet 25.2V
Bosch	BBH625W60/02	Athlet 25.2V
Bosch	BCH6ATH25L/01	Athlet 25.2V
Bosch	BCH6ALL/02	Athlet 25.2V
Bosch	BCH6LNG25/02	Athlet 25.2V
Bosch	BCH65RT25/02	Athlet 25.2V
Bosch	BCH6LNG25/01	Athlet 25.2V
Bosch	BCH65RT25/01	Athlet 25.2V
Bosch	BCH6L2560/01	Athlet 25.2V
Bosch	BCH6ALL/01	Athlet 25.2V
Bosch	BCH65ALL/02	Athlet RuntimePlus 25.2V
Bosch	BCH65RT25A/01	Athlet RuntimePlus 25.2V
Bosch	BCH6ATH25K/06	
Bosch	BCH6ATH25K/03	
Bosch	BCH628ATH/03	
Bosch	BCH6LNG25/03	
Bosch	BCH6LNG25/06	
Bosch	BCH65RT25/05	
Bosch	BCH65RT25/03	
Bosch	BCH6L2560/03	
Bosch	BCH65ALL/03	
Bosch	BCH6L2560/04	
Bosch	BBH62860/03	

Bosch	BCH6ATH25/06	
Bosch	BCH6ATH25/03	
Bosch	BBH625W60/03	
Bosch	BBH625W60/06	
Bosch	BCH6L2560/09	
Bosch	BCH6ATH25/09	
Bosch	BCH6AT25TW/02	Athlet 25.2V
Bosch	BCH6AT25AU/02	Athlet 25.2V
Bosch	BCH625KTGB/01	Athlet 25.2V
Bosch	BCH6AT25TW/01	Athlet 25.2V
Bosch	BCH6A25KCN/02	Athlet 25.2V
Bosch	BCH6AT25JP/02	Athlet 25.2V
Bosch	BCH6A25KCN/01	Athlet 25.2V
Bosch	BCH625KTGB/02	Athlet 25.2V
Bosch	BCH6AT25AU/01	Athlet 25.2V
Bosch	BCH6AT25JP/01	Athlet 25.2V
Bosch	BCH65MGKGB/02	Athlet RuntimePlus 25.2V
Bosch	BCH625KTGB/03	
Bosch	BCH6A25KCN/06	
Bosch	BCH6A25KCN/03	
Bosch	BCH6AT25AU/03	
Bosch	BCH6AT25TW/03	