


ANTALYA WLS

- (DE) Montageanleitung
- (IT) Istruzioni di montaggio
- (PL) Instrukcja montażu
- (FR) Notice de montage
- (NL) Handleiding voor de montage
- (RO) Instrucțiuni de asamblare
- (GB) Assembly instructions
- (SK) Montážný návod
- (TR) Montaj talimatı
- (CZ) Montážní návod
- (RU) Инструкция по монтажу
- (HU) Szerelési útmutató



8 x (8x90) m	4 x (8x60) a	12 x O8 d	12 x M8 e	9 x (4x16) f	10 x (5x35) i	8 x g
10 x 50mm r	12 x j	18x k		2x 1	4x 2	

