


INTRODUCTION

Congratulations on your new Dartboard purchase! Keep this information for future reference.

WARNING!

Not suitable for Children under 36 Months. Contains small parts. Chocking hazard. Contains long cord. Strangulation hazard. This toy contains magnets or magnetic parts. Magnets that attract other magnets or metallic parts in the human body can cause severe or deadly injury. Immediately approach a doctor if a magnet has been swallowed or inhaled. ATTENTION: Please retain this information.

PHYSICAL DESCRIPTIONS




INSTALLATION

1. Select a suitable location with about 2.5 m of open space. "Toe-line" should be 2.37 m from the face of the board for throwing distance.
2. Use the cord to hang the Dart game on a hook (not included).

TIPS AND TECHNIQUES

TIP 1: A proper stance is to align your hand, elbow, shoulder, hip and foot. If you are using right hand, then turn the right side of your body facing the board. Put your weight on your right foot in the front, slightly lean forward, and balance with the left foot. If you are using left hand, then do it vice versa.

TIP 2: The throwing motion should be from your elbow out. Keep your body steady and use only your hand, wrist and forearm. Bring your forearm slightly back, and with a fluid motion throw the dart toward the board. Follow through the throw by pointing the index finger at the area that you are aiming.



Manufacturer

Carrmco GmbH & Co. KG
Mühlenweg 144
22844 Norderstedt
Germany
www.carrmco.com
Made in China

Importer

3e oem sports AG
Flurweg 11
82402 Seeshaupt
Germany



6+




EINFÜHRUNG

Herzlichen Glückwunsch zum Kauf Ihres neuen Dartboards! Bitte bewahren Sie diese Information auf.

WARNUNG

Nicht für Kinder unter 36 Monaten geeignet. Enthält Kleinteile. Erstickungsgefahr. Enthält Lange Schnur / Kordel. Strangulationsgefahr. Dieses Spielzeug enthält Magnete oder magnetische Bestandteile. Magnete, die im menschlichen Körper einander oder einen metallischen Gegenstand anziehen, können schwere oder tödliche Verletzungen verursachen. Ziehen Sie sofort einen Arzt zu Rate, wenn Magnete verschluckt oder eingeatmet wurden.


BESCHREIBUNG DES DARTBOARDS**ANLEITUNG ZUM AUFHÄNGEN**

1. Wählen Sie einen geeigneten Ort mit ca. 2,5 m freiem Platz. Die Wurfentfernung zwischen Dartscheibe und Spieler muss 2,37 m betragen.
2. Nutzen Sie die Schnur, um das Dartboard z.B. auf einen Haken aufzuhängen (Haken nicht enthalten).

TIPPS AND TECHNIKEN

TIPP 1: Sie stehen richtig, wenn Ihre Hand, die Schulter, die Hüfte und der Fuß in einer Linie stehen. Wenn Sie mit der rechten Hand werfen, drehen Sie sich mit der rechten Körperhälfte zum Board. Verlagern Sie Ihr Gewicht auf den rechten Fuß, beugen Sie sich leicht nach vorne und balancieren Sie Ihren Stand dann mit dem linken Fuß aus. Wenn Sie Linkshänder sind, verfahren Sie entsprechend.

TIPP 2: Die Wurfbewegung muss aus Ihrem Ellenbogen kommen. Halten Sie Ihren Körper gerade und benutzen Sie nur Ihre Hand, das Handgelenk und den Unterarm. Bewegen Sie Ihren Unterarm leicht zurück und werfen Sie den Dart in einer fließenden Bewegung auf das Board. Bewegen Sie sich so, dass Ihr Zeigefinger nach dem Wurf auf Ihr Ziel zeigt.

**Manufacturer**

Carrromco GmbH & Co. KG
Mühlenweg 144
22844 Norderstedt
Germany
www.carrromco.com
Made in China

Importer

3e oem sports AG
Flurweg 11
82402 Seeshaupt
Germany

**6+**