

Passend für die folgenden Modelle:

NEFF	K1514X0GB/31	K1514
NEFF	K1544X0/32	KI331
NEFF	K3634X0/41	KD140
NEFF	K8525X1GB/02	k8525
NEFF	K5654X0/35	
NEFF	K1614X2/01	KI120SC
NEFF	K1604X2FF/01	KI220SC
NEFF	K1664X0/31	
NEFF	K5634X0/41	
NEFF	K1624X0/41	KI140
NEFF	K1614X0/41	KI120
NEFF	K3664X0/32	KD340
NEFF	K5714X0/31	
NEFF	K1604X0/31	KI220
NEFF	K1604X0/32	KI220
NEFF	K5534X0/33	KI315
NEFF	K6655X0/01	
NEFF	K5524X0IE/33	KI135SC
NEFF	K3634X0/42	KD140
NEFF	K3614X0/41	KD120
NEFF	K4435X2IE/02	
NEFF	K8514X1FF/01	KG411
NEFF	K1514X1FF/02	KI111SC
NEFF	K5524X0/44	KI135SC
NEFF	K1664X2/01	
NEFF	K5624X1GB/01	
NEFF	K5614X0GB/32	
NEFF	K1534X0/31	KI311
NEFF	K5524X0IE/31	KI135SC
NEFF	K8525X2/01	
NEFF	K1514X1/02	KI111SC
NEFF	K1514X1GB/02	KI111SC
NEFF	K5654X0GB/33	
NEFF	K8525X2FF/01	
NEFF	K1514X0/41	KI111
NEFF	K4425X1/01	
NEFF	K8525X1FF/01	KG520
NEFF	K1604X2/01	KI220SC
NEFF	K5544X0/32	KI335
NEFF	K1694X2FF/01	KI240SC
NEFF	K1574X0/32	KT411
NEFF	K1544X1FF/01	KI331SC
NEFF	K1504X0/32	
NEFF	K1644X2/01	KI340SC
NEFF	K1514X0GB/44	K1514
NEFF	K5654X0/31	

NEFF	K1514X0/32	KI111
NEFF	K3634X1FF/02	KD140SC
NEFF	K1664X0/32	
NEFF	K5524X0/41	KI135SC
NEFF	K5534X0/32	KI315
NEFF	K6615X0/01	
NEFF	K5654X0GB/34	
NEFF	K8514X1/02	KG411
NEFF	K1514X0/43	KI111
NEFF	K1534X0/32	KI311
NEFF	K1524X1/01	KI131SC
NEFF	K1644X0/35	KI340
NEFF	K1644X0/33	KI340
NEFF	K5654X2FF/01	
NEFF	K5514X0/31	KI115
NEFF	K8525X1GB/01	k8525
NEFF	K8525X1/01	kg520
NEFF	K8525X1/02	kg520
NEFF	K8525X0/31	KG520
NEFF	K8525X0GB/31	K8525
NEFF	K8514X0/31	KG411
NEFF	K1534X1FF/01	
NEFF	K6625X0/01	
NEFF	K6645X0/01	
NEFF	K5734X0/32	
NEFF	K5734X0/31	
NEFF	K5634X1GB/03	
NEFF	K5634X1GB/01	
NEFF	K5634X0GB/42	
NEFF	K5634X0GB/41	
NEFF	K5634X0/44	
NEFF	K5634X0/43	
NEFF	K5634X0/42	
NEFF	K5524X0/43	KI135SC
NEFF	K1674X0/32	
NEFF	K5524X0/42	KI135SC
NEFF	K1514X0/31	KI111
NEFF	K1674X0/31	
NEFF	K1504X0/31	
NEFF	K1514X0/42	KI111
NEFF	K1664X2FF/01	
NEFF	K3664X1/02	KD340SC
NEFF	K1514X0GB/41	K1514
NEFF	K1514X0GB/32	K1514
NEFF	K3664X1/01	KD340SC
NEFF	K1514X0GB/43	K1514
NEFF	K1514X0GB/42	K1514
NEFF	K1534X1/01	

NEFF	K3634X1FF/01	KD140SC
NEFF	K1514X1GB/01	KI111SC
NEFF	K3634X1/03	KD140SC
NEFF	K3634X1/01	KD140SC
NEFF	K3614X0/42	KD120
NEFF	K4435X2IE/01	
NEFF	K1564X0/32	
NEFF	K1574X0/31	KT411
NEFF	K1614X0/31	KI120
NEFF	K1624X0/44	KI140
NEFF	K1624X0/43	KI140
NEFF	K1624X0/42	KI140
NEFF	K1614X0/42	KI120
NEFF	K1564X0/31	
NEFF	K5514X0/32	KI115
NEFF	K5524X0IE/32	KI135SC
NEFF	K8514X1/01	KG411
NEFF	K1694X2/02	KI240SC
NEFF	K1694X0/32	KI240
NEFF	K1694X2/01	KI240SC
NEFF	K1624X2/01	KI140SC
NEFF	K1544X1/01	KI331SC
NEFF	K1644X2FF/01	KI340SC
NEFF	K1644X2/02	KI340SC
NEFF	K8524X4GB/01	
NEFF	K8524X4GB/02	
NEFF	K8525X3GB/01	
NEFF	K1544X0/33	KI331
NEFF	K4435X2/01	
NEFF	K1644X0/34	KI340
NEFF	K1544X0/31	KI331
NEFF	K1644X0/31	KI340
NEFF	K4425X2IE/01	
NEFF	K1514X1/01	KI111SC
NEFF	K5604X0/31	
NEFF	K5534X0/31	KI315
NEFF	K5604X0GB/31	
NEFF	K5604X0/41	
NEFF	K5604X0GB/42	
NEFF	K8514X2/01	
NEFF	K5614X0/31	
NEFF	K5614X0GB/31	
NEFF	K5654X2/01	
NEFF	K5514X0/42	KI115
NEFF	K5654X2/02	
NEFF	K5624X0GB/31	
NEFF	K5624X0/31	
NEFF	K5624X0GB/32	

NEFF	K5624X0IE/31	
NEFF	K5644X0/31	
NEFF	K5614X1GB/01	
NEFF	K5544X0/31	KI335
NEFF	K5714X0/32	
NEFF	K1634X0/31	KI320
NEFF	K1634X2FF/01	
NEFF	K1634X2/01	
NEFF	K1524X1FF/01	KI131SC
NEFF	K1524X0/45	KI131
NEFF	K1524X0/44	KI131
NEFF	K1524X0/43	KI131
NEFF	K1524X0/42	KI131
NEFF	K1524X0/41	KI131
NEFF	K3614X0/31	KD120
NEFF	K3614X1/01	KD120SC
NEFF	K5654X0GB/31	
NEFF	K5654X0GB/32	
NEFF	K5654X0/34	
NEFF	K5654X0/33	
NEFF	K1514X1FF/01	KI111SC
NEFF	K8514X2FF/01	
NEFF	K1694X0/31	KI240
NEFF	K5654X0/32	