



Installation and usage of electric screen:

1. Take out the screen after opening the carton, meanwhile do not impact the screen.
2. According to venue and projecting requirements, fix up the wall shelf securely. (Note that the two wall shelves must be at the same level, otherwise screen surface will decline to one side)
3. Hang the screen on the wall shelf.
4. Once the direction red light is shown on the switch box after the power on, startup the up and down switch on the switch box, notice the screen's normal work.
5. Remote / manual dual-use type, you can control the screen in different ways according to your choice. (Avoid remote to be broken)



Wall mounted

There is a key ring on the bracket at both ends of the screen, when you need to hang projection screen on the wall, you should hammer down nails or install screws at the corresponding position on the wall first , then hang up the screen.



Ceiling style:

When you need to hang projection screen on the ceiling, you should install two pieces of pothooks at the corresponding position on the ceiling first, then latch on hanging jack which is on the end cap of projection screen.

