







Soul

8141/2500/5010/2300  
2100/5010/2500/8142



- |           |  |           |   |
|-----------|--|-----------|---|
| <b>D</b>  | MONTAGEANLEITUNG<br>BEDIENUNGSANLEITUNG                | <b>GB</b> | ASSEMBLY INSTRUCTIONS<br>INSTRUCTION MANUAL         |
| <b>NL</b> | HANDLEIDING VOOR DE MONTAGE<br>GEBRUIKSAANWIJZING      | <b>PL</b> | INSTRUKCJA MONTAŻU<br>INSTRUKCJA OBSŁUGI            |
| <b>TR</b> | MONTAJ TALIMATI<br>KULLANIM KLAVUZU                    | <b>RU</b> | ИНСТРУКЦИЯ ПО МОНТАЖУ<br>ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ |
| <b>RO</b> | INSTRUCȚIUNI DE INSTALARE<br>INSTRUCȚIUNI DE UTILIZARE | <b>IT</b> | ISTRUZIONI DI MONTAGGIO<br>MANUALE DI ISTRUZIONI    |
| <b>FR</b> | NOTICE DE MONTAGE<br>MANUEL INSTRUCTIONS               | <b>SK</b> | MONTÁŽNY NÁVOD<br>NÁVOD NA POUŽITIE                 |
| <b>HU</b> | KÖZGYŰLÉS UTASÍTÁSOK<br>KEZELÉSI UTASÍTÁS              | <b>CZ</b> | MONTÁŽNÍ NÁVOD<br>NÁVOD K POUŽITÍ                   |
| <b>SI</b> | NAVODILA ZA MONTAŽO<br>NAVODILA ZA UPORABO             | <b>PT</b> | INSTRUÇÕES DE MONTAGEM<br>MANUAL DO USUÁRIO         |
| <b>ES</b> | INSTRUCCIONES DE MONTAJE<br>MANUAL DEL USUARIO         | <b>HR</b> | UPUTE ZA MONTAŽU<br>UPUTE ZA UPOTREBU               |





0089





0089





0019



0019



**0058**





**0058**

L



R





<b>g</b> H-120/150  X1	<b>V</b> H- 120/150  X1	<b>i</b> L- 5  X1	<b>S</b> H- 120/150  <b>s</b> <sub>1</sub> X4	<b>q</b> M8*35  X8
------------------------------	-------------------------------	-------------------------	--	--------------------------

[mm]


<b>V</b> H- 120/150  X3	<b>i</b> L- 5  X1	<b>S</b> H- 120/150  <b>s</b> <sub>1</sub> X1	<b>q</b> M8*35  X2
-------------------------------	-------------------------	--	--------------------------




[mm]








<b>i</b> L- 5  X1	<b>S</b> H- 120/150  <b>s</b> <sub>1</sub> X2	<b>q</b> M8*35  X4
-------------------------	--	--------------------------










[mm]















0019





<b>g</b> H-120/150  X1	<b>v</b> H- 120/150  X4	<b>i</b> L-5  X1	<b>S</b> H- 120/150  <b>S</b> <sub>1</sub> X7	<b>q</b> M8*35  X14
---	---	---	--	--










0058














0019







Name · Naam · Nazwa · İsim · Название · Nume · Nome · Název · Názov ·  
 Název · Neve

**SOUL**

Typ · Type · Tip · Тип · Tipo · Típus

<b>g</b> H-120/150 	<b>V</b> H- 120/150 	<b>S</b> H- 120/150 	<b>q</b> M8*35 	[mm]
--	---	---	--	------

