

# Instruction Manual


## Battery Installation:

1. Unscrew the upper cap with anti-clockwise direction and remove it from the body
2. Fill 6xAAA batteries into the battery compartment as per the picture showing.
3. Put the upper cap back to the body and turn it to fix with clockwise direction.



## Fill the peppercorns:

4. Unscrew the lower part of transparent container with clockwise direction and remove it from the body.
5. Fill the peppercorns or rock salt into the container to 80% full in the chamber.
6. Replace the container to the body and unscrew it to fix.



## Operating your pepper mill:

7. Turn the adjusting knob on the top to adjust the grind size. Turn clockwise for a finer grind and counter-clockwise for a coarser grinder.
8. Turn the mill upside down to start grinding.



## Notes:

The machine may stuck during using, pleas adjust the top adjusting knob with counter-clockwise direction.

For batteries, Alkaline batteries are recommended.

Always keep clean and avoid contacting with water.