

Passend für die folgenden Modelle:

Marke	Typennummer	Modell
Neff	E1531W1/01	MEGA 1535A
Neff	E1531G0/01	MEGA 1530
Neff	E1521S0/01	MEGA 1521
Neff	E1531P0/01	MEGA 1537
Neff	E1521G0/04	MEGA 1520
Neff	E1531S1/04	MEGA 1531A
Neff	E1441W0EU/02	
Neff	E1541W0EU/04	
Neff	E1521G0/01	MEGA 1520
Neff	E1441S0EU/01	
Neff	E1441W0EU/01	
Neff	E1531W0/01	MEGA 1535
Neff	E1541W0EU/01	
Neff	E1441S0EU/02	
Neff	E1531S0/01	MEGA 1531
Neff	E1441N0EU/01	
Neff	E1531S1/01	MEGA 1531A
Neff	E1531N1/04	MEGA 1539A
Neff	E1521W0/01	MEGA 1525
Neff	E1441G0EU/01	
Neff	E1441G0EU/02	
Neff	E1441N0EU/02	
Neff	E1441N0EU/03	
Neff	E1521P0/01	MEGA 1527
Neff	E1521P0/04	MEGA 1527
Neff	E1521S0/04	MEGA 1521
Neff	E1521W0/04	MEGA 1525

Neff	E1531G1/01	MEGA 1530A
Neff	E1531G1/04	MEGA 1530A
Neff	E1531N1/01	MEGA 1539A
Neff	E1531W1/04	MEGA 1535A
Neff	E1541N0EU/01	
Neff	E1541N0EU/04	
Neff	E1541S0EU/01	
Neff	E1541S0EU/04	
Neff	B1531N2/01	MEGA4539A
Neff	E3441S0EU/02	
Neff	E3431N0/03	MEGA 3439
Neff	B1481U2/01	MEGA CLASSIC BLAU
Neff	B1472N3FF/01	
Neff	E1521N2/01	MEGA1529A
Neff	E1521A2/01	MEGA1527A
Neff	E3410N0/02	MEGA 3419
Neff	U1641B0/01	MEGA5640
Neff	B1431N2/01	MEGA4439A
Neff	U1641W0/03	MEGA5645
Neff	B1472W3FF/01	
Neff	E3461N2/05	MEGA3469
Neff	E1571N1/01	MEGA 1579 A
Neff	E3410G0/01	MEGA 3410
Neff	E1441B2/02	MEGA1440A
Neff	U1641B0/03	MEGA5640
Neff	E3441N0EU/04	
Neff	E3461N0/03	MEGA 3469
Neff	B1481K2/01	MEGA CLASSIC WEISS
Neff	U1641W0/01	MEGA5645

Neff	E1441W2/01	MEGA1445A
Neff	E1951B2/01	MEGA1950EXCELLENT
Neff	B1431N2/05	MEGA4439A
Neff	B1541W2/01	MEGA4545A
Neff	E1441W2/02	MEGA1445A
Neff	E3431W0/02	MEGA 3435
Neff	U1641S0/03	MEGA5641
Neff	E1541B2/01	MEGA1540A
Siemens	HB95054CC/01	
Neff	E1461N2/01	MEGA1469A
Neff	E1441N2/01	MEGA1449A
Neff	E3441S0EU/01	
Neff	B1951N2/01	MEGA4959 EXCELLENT
Neff	E1631N2/01	MEGA1639
Neff	E1521J2/01	MEGA1523A
Neff	E1541N2/05	MEGA1549A
Neff	U1641S0/02	MEGA5641
Neff	E1631W2/01	MEGA1635
Neff	B1472S3FF/01	
Neff	B1420N0/02	MEGA 4429
Neff	B1481C2/01	MEGA CLASSIC SCHWARZ
Neff	E3441N0EU/03	
Neff	E3410W0/01	MEGA 3415
Neff	E3431N0/02	MEGA 3439
Neff	E1468C2/01	MEGA1468NOST
Neff	E1431W2/01	MEGA1435A
Neff	E1541S2/01	MEGA1541A
Neff	E1521W2/01	MEGA1525A
Neff	E1631B2/01	MEGA1630

Neff	E1951W2/01	MEGA1955EXCELLENT
Neff	E3431S0/02	MEGA 3431
Neff	B1472W2FF/01	
Neff	E3431S0/01	MEGA 3431
Neff	E1431B2/01	MEGA1430A
Neff	E3461N2/01	MEGA3469
Neff	U1641S0/01	MEGA5641
Neff	B1488C2/01	MEGA4488 NOSTALGIE
Neff	B1531N2/05	MEGA4539A
Neff	E3461B2/01	MEGA3460
Neff	E1461N2/05	MEGA1469A
Neff	E1461W2/01	MEGA1465A
Neff	U1641N0/02	MEGA5649
Neff	E1631N0/03	MEGA 1639
Neff	E3431N0/04	MEGA 3439
Neff	E1951N2/01	MEGA1959EXCELLENT
Neff	B1431W2/01	MEGA4435A
Neff	E1441B2/01	MEGA1440A
Neff	E3431G0/03	MEGA 3430
Neff	B1471N2EU/05	
Neff	B1541N2/05	MEGA4549A
Neff	E3431W0/04	MEGA 3435
Neff	E3431G0/04	MEGA 3430
Neff	E1541W2/01	MEGA1545A
Neff	E3410S0/01	MEGA 3411
Neff	E3410G0/03	MEGA 3410
Neff	E3431W0/01	MEGA 3435
Neff	B1472S2FF/01	
Neff	B1472N2FF/01	

Neff	E1431J2/01	MEGA1433A
Neff	B1541J2/01	MEGA4543A
Neff	E1441N2/05	MEGA1449A
Neff	E3461B0/01	MEGA 3460
Neff	E3461N0/01	MEGA 3469
Neff	E1521N2/05	MEGA1529A
Neff	U1641B0/02	MEGA5640
Neff	E1461B2/01	MEGA1460A
Neff	E1541N2/01	MEGA1549A
Neff	U1641N0/01	MEGA5649
Neff	U1641W0/02	MEGA5645
Neff	B1431S2/01	MEGA4431A
Neff	B1471N2EU/01	
Neff	B1471S2EU/01	
Neff	B1481J2/01	MEGA CLASSIC PASTELLWEISS
Neff	B1410N0/02	MEGA 4419
Neff	B1420N0/01	MEGA 4429
Neff	B1420N0/03	MEGA 4429
Neff	B1481V2/01	MEGA CLASSIC GRUEN
Neff	B1541A2/01	MEGA4547A
Neff	B1541B2/01	MEGA4540A
Neff	B1541N2/01	MEGA4549A
Neff	B1541S2/01	MEGA4541A
Neff	B1951N2/05	MEGA4959 EXCELLENT
Neff	E1901W0CC/01	
Neff	E1901S0CC/01	
Neff	E3461B0/04	MEGA3460
Neff	E3461S0/04	MEGA3461
Neff	E3461S0/01	MEGA 3461

Neff	E3461N1/01	MEGA3469
Neff	E3461W0/04	MEGA3465
Neff	E3461W0/01	MEGA 3465
Neff	E1461A2/01	MEGA1467A
Neff	E1521B2/01	MEGA1520A
Neff	E1521S2/01	MEGA1521A
Neff	E1631N2/05	MEGA1639
Neff	E1631S2/01	MEGA1631
Neff	E1641N2/01	MEGA1649
Neff	E1641N2/05	MEGA1649
Neff	E1441N2/02	MEGA1449A
Neff	E1951N0/09	MEGA1959EXCELLENT
Neff	B1472N3FF/05	
Neff	B1472N1FF/01	
Neff	E1431A2/01	MEGA1437A
Neff	E1431N2/01	MEGA1439A
Neff	E1431S2/01	MEGA1431A
Neff	E1431N2/05	MEGA1439A
Neff	E1951N2/05	MEGA1959EXCELLENT
Neff	E3410N0/01	MEGA 3419 e
Neff	U1641N0/03	MEGA5649
Neff	E3431G0/01	MEGA 3430
Neff	E3431G0/02	MEGA 3430
Neff	E3431N0/01	MEGA 3439
Neff	E3431S0/04	MEGA 3431
Neff	E3441W0EU/01	
Neff	E3441W0EU/02	
Neff	E3461W2/01	MEGA3465
Siemens	HB95054CC/06	

Siemens	HB95055CC/01	
Siemens	HB95055CC/05	
Neff	E1431N1/01	MEGA1439A
Neff	B1561W0/04	MEGA 4565
Neff	E1631B0/01	MEGA 1630
Neff	E1431N0/02	MEGA 1439
Neff	B1641N2/05	MEGA4649
Neff	B1431W0/01	MEGA4435
Neff	E1471N0/01	MEGA1479
Neff	B1472W0FN/01	
Neff	B1541N2EU/01	MEGA4549B
Neff	B1481N0/01	MEGA4489
Neff	B1541N0/01	MEGA 4549
Neff	B1561N0/04	MEGA 4569
Neff	E1641N0/01	MEGA1649
Neff	E1431N0/03	MEGA 1439
Neff	E1541W1/01	MEGA 1545 A
Neff	U1561N0/01	MEGA 5569
Neff	B1472N0FN/03	
Neff	B1441N0EU/03	MEGA 4449
Neff	B1488C0/01	MEGA4488 Nostalgie schwarz
Neff	U1561G0/04	MEGA 5560
Neff	B1641N0/01	MEGA 4649
Neff	U1561S0/04	MEGA 5561
Neff	B1488K0/04	MEGA4488 Nostalgie weiss
Neff	E1431J1/01	MEGA1433A
Neff	B1481J0/01	MEGA4483
Neff	B1841N2/02	MEGA SE4849
Neff	B1548C0/04	MEGA 4548 NOSTALGIESCHWARZ

Neff	B1481U0/01	MEGA CLASSIC BLAU
Neff	E1851N2/05	MEGA SE1859
Neff	E1951N0/04	MEGA1959EXCELLENT
Neff	B1420W0/01	MEGA 4425
Neff	E1951W0/04	MEGA1955EXCELLENT
Neff	B1641S2/01	MEGA4641
Neff	E1431G0/04	MEGA 1430
Neff	B1861N0/01	MEGA SE 4869
Neff	E1441N0/02	MEGA 1449 A
Neff	B1541B1/01	MEGA4540A
Neff	B1541U0EU/04	Classic blau
Neff	B1441N0EU/01	MEGA 4449
Neff	E1441W1/01	MEGA1445A
Neff	E1420S0/01	MEGA 1421
Neff	B1441W0EU/02	MEGA 4445
Neff	E1441N1/01	MEGA1449A
Neff	B1641A0/01	MEGA 4647 Trend Aluminium
Neff	E1420N0/03	MEGA 1429
Neff	E1641B0/01	MEGA1640
Neff	B1641W0/01	MEGA 4645
Neff	E1420N0/01	MEGA 1429
Neff	E1431W0/04	MEGA 1435
Neff	E1420S0/02	MEGA 1421
Neff	B1431W1/01	MEGA4435A
Neff	B1561N0GB/01	B1561 STAINLESSSTEEL
Neff	E1440W0/01	MEGA 1445
Neff	E1471B0/01	MEGA1470
Neff	B1541C0EU/01	Classic schwarz
Neff	B1891N0/01	MEGA SE 4899

Neff	E1441N0/01	MEGA 1449 A
Neff	B1420S0/02	MEGA 4421
Neff	U1561W0/01	MEGA 5565
Neff	E3491S2/01	MEGA3491A
Neff	E1851N0/01	MEGA SE 1859
Neff	B1481N1FF/01	
Neff	E1461J0/01	MEGA1463
Neff	B1548C0/01	MEGA 4548 NOSTALGIESCHWARZ
Neff	B1641N2/01	MEGA4649
Neff	B1471W1EU/01	
Neff	B1541S1/01	MEGA4541A
Neff	E1431G0/01	MEGA 1430
Neff	B1481W0/01	MEGA4485
Neff	E1521S1/01	MEGA 1521 A
Neff	B1541W1/01	MEGA4545A
Neff	E1641N1/03	MEGA1649
Neff	E1441G0/02	MEGA 1440 A
Neff	E1461W0/01	MEGA1465
Neff	B1472N0FN/01	
Neff	E1851N2/01	MEGA SE1859
Neff	E1441N0/03	MEGA 1449 A
Neff	E1631W0/01	MEGA 1635
Neff	B1441N0EU/02	MEGA 4449
Neff	E1440S0/02	MEGA 1441
Neff	E3491W2/01	MEGA3495A
Neff	B1541N0/04	MEGA 4549
Neff	B1431S1/01	MEGA4431A
Neff	E1541N1/01	MEGA 1549 A
Neff	B1471N0EU/03	

Neff	U1641N2/01	MEGA5649
Neff	B1541C0EU/04	Classic schwarz
Neff	B1420W0/02	MEGA 4425
Neff	B1541V0EU/04	Classic gruen
Neff	E1641W0/01	MEGA1645
Neff	B1488K0/01	MEGA4488 Nostalgie weiss
Neff	E1440W0/02	MEGA 1445
Neff	E1420G0/03	MEGA 1420
Neff	E1440S0/01	MEGA 1441
Neff	E1420G0/02	MEGA 1420
Neff	B1481N0/03	MEGA4489
Neff	U1561S0/01	MEGA 5561
Neff	E1441S0/02	MEGA 1441 A
Neff	U1561G0/01	MEGA 5560
Neff	E1440N0/02	MEGA 1449
Neff	B1471S0EU/01	
Neff	E1461B0/01	MEGA1460
Neff	E1440G0/02	MEGA 1440
Neff	E1541B1/01	MEGA 1540 A
Neff	B1541G0/04	MEGA 4540
Neff	E1461N0/03	MEGA1469
Neff	E1441G0/01	MEGA 1440 A
Neff	B1471W0EU/01	
Neff	B1472W1FF/01	
Neff	B1641N0/03	MEGA 4649
Neff	E1521B1/01	MEGA 1520 A
Neff	U1561W0/04	MEGA 5565
Neff	B1541W0/01	MEGA 4545
Neff	B1548K0/04	MEGA 4548 NOSTALGIEWEISS

Neff	B1488C0/04	MEGA4488 Nostalgie schwarz
Neff	E1521N1/01	MEGA 1529 A
Neff	B1541N0/02	MEGA 4549
Neff	E1441B1/01	MEGA1440A
Neff	E1571Z1/01	MEGA 1576 A
Neff	E1641S0/01	MEGA1641
Neff	E1571Z1/05	MEGA 1576 A
Neff	E1431W0/02	MEGA 1435
Neff	E1431S1/01	MEGA1431A
Neff	B1541K0EU/01	Classic weiss
Neff	U1641S2/01	MEGA5641
Neff	U1641B2/01	MEGA5640
Neff	B1431N0/01	MEGA4439
Neff	E1431S0/01	MEGA 1431
Neff	E1461S0/01	MEGA1461
Neff	B1472S0FN/01	
Neff	E1431N0/04	MEGA 1439
Neff	B1472S1FF/01	
Neff	B1481S0/01	MEGA4481
Neff	E1420W0/02	MEGA 1425
Neff	E1571B1/01	MEGA 1570 A
Neff	B1471N1EU/01	
Neff	E3491N2/01	MEGA3499A
Neff	B1541U0EU/01	Classic blau
Neff	B1861N2/02	MEGA SE4869
Neff	B1541J1/01	MEGA4543A
Neff	E1631S0/01	MEGA 1631
Neff	E1571W1/01	MEGA 1575 A
Neff	B1481W1FF/01	

Neff	E1420W0/01	MEGA 1425
Neff	E1431W1/01	MEGA1435A
Neff	E1420G0/01	MEGA 1420
Neff	B1431N1/01	MEGA4439A
Neff	B1951N0/08	MEGA4959EXCELLENT
Neff	E1431S0/02	MEGA 1431
Neff	B1541S0/04	MEGA 4541
Neff	E1440N0/01	MEGA 1449
Neff	B1541V0EU/01	Classic gruen
Neff	B1420S0/01	MEGA 4421
Neff	B1471N1EU/06	
Neff	E1431B1/01	MEGA1430A
Neff	E1631N0/01	MEGA 1639
Neff	B1481K0/01	MEGA CLASSIC WEISS
Neff	E1471S0/01	MEGA1471
Neff	B1841N0/01	MEGA SE 4849
Neff	B1541A1/01	MEGA4547A
Neff	B1891N2/05	MEGA SE4899
Neff	B1441S0EU/01	MEGA 4441
Neff	E1471W0/01	MEGA1475
Neff	B1541G0/01	MEGA 4540
Neff	B1891N2/02	MEGA SE4899
Neff	B1441S0EU/02	MEGA 4441
Neff	E1431G0/02	MEGA 1430
Neff	B1481S1FF/01	
Neff	B1641Z0/01	MEGA 4646 TREND ALUMINIUM
Neff	B1548K0/01	MEGA 4548 NOSTALGIEWEISS
Neff	E1468C0/01	MEGA 1468
Neff	E1441W0/01	MEGA 1441 A

Neff	E1571S1/01	MEGA 1571 A
Neff	B1541P0/01	MEGA 4547
Neff	B1641W2/01	MEGA4645
Neff	B1541K0EU/04	Classic weiss
Neff	B1541P0/04	MEGA 4547
Neff	E1440G0/01	MEGA 1440
Neff	E1471N0/03	MEGA1479
Neff	E1431S0/04	MEGA 1431
Neff	E1431W0/01	MEGA 1435
Neff	E1440N0/03	MEGA 1449
Neff	E1441S0/01	MEGA 1441 A
Neff	E1441W0/02	MEGA 1445 A
Neff	E1420N0/02	MEGA 1429
Neff	E1431N0/01	MEGA 1439
Neff	B1841N2/05	MEGA SE4849
Neff	B1861N2/05	MEGA SE4869
Neff	B1541N1/01	MEGA4549A
Neff	E3491N2/05	MEGA3499A
Neff	B1541S0/01	MEGA 4541
Neff	B1541W0/04	MEGA 4545
Neff	B1561N0/01	MEGA 4569
Neff	B1561N0GB/04	B1561 STAINLESSSTEEL
Neff	B1561S0/01	MEGA 4561
Neff	B1561S0/04	MEGA 4561
Neff	B1561W0/01	MEGA 4565
Neff	B1641A2/01	MEGA4647
Neff	U1561N0/04	MEGA 5569
Neff	U1641N2/05	MEGA5649
Neff	E1951B0/04	MEGA1950EXCELLENT

Neff	B1441W0EU/01	MEGA 4445
Neff	E1521J1/01	MEGA 1523 A
Neff	E1521W1/01	MEGA 1525 A
Neff	E1541S1/01	MEGA 1541 A
Neff	E1641N0/03	MEGA1649
Neff	E1461N0/01	MEGA1469
Neff	E1468C0/04	MEGA 1468
Neff	B1431S0/01	MEGA4431
Neff	B1471S1EU/01	
Neff	B1471N0EU/01	
Neff	B1481C0/01	MEGA CLASSIC SCHWARZ
Neff	B1481B0/01	MEGA4480
Neff	B1481V0/01	MEGA CLASSIC GRUEN
Neff	B1531N1/01	MEGA4539A
Neff	B1541A1/04	MEGA4547A
Neff	B1641S0/01	MEGA 4641
Neff	B1951N0/01	MEGA4959EXCELLENT
Neff	B1431N0/03	MEGA4439
Neff	E1410S0/01	MEGA 1411
Neff	E1410N0/02	MEGA 1419
Neff	E1410N0/01	MEGA 1419
Neff	B1881N2/05	MEGA SL4889
Neff	B1881N0/01	MEGA SL 4889
Neff	B1881A2/02	MEGASL4887
Neff	B1831N3/03	MEGASL 4839A
Neff	B1831N2/05	MEGA SL4839
Neff	B1831N2/02	MEGA SL4839
Neff	B1771W2/01	MEGACOMPACT4775
Neff	B1771W0/01	Mega compact 4775

Neff	B1771N2/05	MEGACOMPACT4779
Neff	B1771N2/01	MEGACOMPACT4779
Neff	B1771N0/01	Mega compact 4779
Neff	B1771A2/01	MEGACOMPACT4777
Neff	B1751W1/01	MEGA COMPACT 4755 A
Neff	B1751W0/01	Mega compact 4755
Neff	B1751S0/01	Mega compact 4751
Neff	B1751N2/05	MEGACOMPACT4759A
Neff	B1751N0/01	Mega compact 4759
Neff	E1431A1/04	MEGA1437A
Neff	E1410G0/01	MEGA 1410
Neff	E1410W0/01	MEGA 1415
Neff	B1751S1/01	MEGA COMPACT 4751
Neff	B1771S2/01	MEGACOMPACT4771
Neff	B1881A3/03	MEGASL 4887A
Neff	E1431A1/01	MEGA1437A
Neff	B1771A0/01	MEGA COMPACT 4777
Neff	B1751N1/01	MEGA COMPACT 4759 A
Neff	B1751N2/01	MEGACOMPACT4759A
Neff	B1881N2/02	MEGA SL4889
Neff	B1881N3/03	MEGASL 4889A
Neff	E1410G0/03	MEGA 1410
Neff	B1771S0/01	Mega compact 4771
Neff	Z1340X2(00)	