


"FLAME" Unterteil 90



D

Montageanleitung

GB

Assembly instructions

NL

Handleiding voor de montage

PL




Instrukcja montazu

TR

Montaj talimati

RU

Инструкция по сборке



Service • Dienstverlening • Serwis • Servis • Сервисная служба

Name • Naam • Nazwa • Isim • Название

FLAME




Typ • Type • Тип • Тип
















TV-Unterteil 90cm

Nr. • No. • Номер

437 503 / 435 290 // 782 349 / 779 765

 **Schwarz / Weiß**



A1  12	B1  12	C1  8x30 12	E10  2 mm 2	F16  Kr.0 mm 2	K11  60x40x20 5	L1  4	M4  BA 128mm 1	N1  4,0 x 30 4
N2  2,7 x 20 3	P2  3,5 x 13 4	P9  3,5 x 25 10	P10  3,5 x 13 kl. Kopf 4	S1  12	W4  1			

