


MONTAGEANLEITUNG

Artikelnummer: WF312386WAA

EINZELBETT 200x90cm



INSTRUCTIONS

IMPORTANT-READ CAREFULLY-RETAIN FOR FUTURE REFERENCE


- a) **WARNING** -Children can become trapped between the bed and the wall, the adjoining pieces of furniture (e.g. cupboards) and the like. To avoid risk of serious injury the distance between the safety barrier and the adjoining structure shall not exceed 75 mm or shall be more than 230 mm.
- b) **WARNING**-Do not use the bed if any structural part is broken or missing; Replacement parts are between requested from the manufacturer or the store.
- c) **WARNING**-Do not climb or wiggle on any non-designated structures.
- d) It is imperative to always follow the installation instructions and manufacturer's use.
- e) The recommended size of the mattress to be used with the bed is **90x200cm**, maximum thickness mattress:**13cm**.
- f) It is necessary to ventilate the room in order to maintain a low level moisture and prevent mold growth in the bed and its periphery.
- g) Joining devices should always be tightened properly and regularly verified. Tighten if necessary.

ANLEITUNGEN


















WICHTIG - SORGFÄLTIG LESEN - FÜR SPÄTERE VERWENDUNG AUFBEWAHREN

- a) **WARNUNG**-Kinder können zwischen dem Bett und der Wand, den angrenzenden Möbelstücken (z. B. Schränken) und der Lücke eingeklemmt werden. Um die Gefahr schwerer Verletzungen zu vermeiden, darf der Abstand zwischen der Sicherheitsbarriere und der angrenzenden Struktur nicht mehr als 75 mm oder mehr als 230 mm betragen.
- b) **WARNUNG**-Das Bett darf nicht benutzt werden, wenn ein Bauteil gebrochen ist oder fehlt;
Ersatzteile sind beim Hersteller oder im Geschäft anzufordern.
- c) **WARNUNG**-Klettern oder wackeln Sie nicht auf nicht dafür vorgesehenen Strukturen.
- d) Befolgen Sie unbedingt die Installationsanweisungen und die Gebrauchsanweisungen des Herstellers.
- e) Die empfohlene Größe der Matratze für das Bett beträgt **90x200cm**, maximale Dicke der Matratze: **13cm**.
- f) Es ist notwendig, den Raum zu lüften, um die Feuchtigkeit niedrig zu halten und Schimmelbildung im Bett und seiner Umgebung zu verhindern.
- g) Die Verbindungselemente sollten immer richtig angezogen sein und regelmäßig überprüft werden. Ziehen Sie sie gegebenenfalls nach.

Stückliste














WF312386WAA


1 x15 	2 x7 	3 x7 	4 x6 
5 x2 	6 x1 	7 x2 	9 x1 
11 x3 	13 x2 	14 x2 	15 x2 
16 x2 	17 x2 	18 x2 	19 x2 
20 x2 			

WF312386WAA


Hardware-Liste

Ax8  M6x80	Bx16  M6x45	Cx1  M4x20	Dx4  M6x25	Ex24  M4x35	Fx38  M4x30
Gx16  M3x12	Hx1 	Jx8 	Kx12 	Lx12 	


Benötigte Werkzeuge (nicht von uns gestellt)



Schritt 1



Schritt 2




Schritt 3

B



8




Schritt 4

B



8




Schritt 5

A



8




Schritt 6

D



4




Schritt 7

E



24




Schritt 8

F



30




Schritt 9

C



1







Schritt 10

K



12






Schritt 11

L



10






Schritt 12

L



2




Schritt 13

F



8



Schritt 14

J




8

G



16



Schritt 15

