



Sie haben sich für eine Uhr entschieden, in der durch den Uhrenhersteller ein Uhrwerk von Ronda eingebaut wurde. Bitte beachten Sie, dass unter der Marke Ronda weder Uhren produziert noch am Markt vertrieben werden.

Käufer und Konsumenten können sich im Falle von Reparaturen, Garantiesprüchen sowie Fragen zur Funktion der Uhr ausschliesslich an die Verkaufsstelle oder den Uhrenhersteller wenden. Entsprechende Informationen sind den Verkaufs- oder Garantiebestimmungen zu entnehmen.

Beschreibung der Anzeige- und Bedienelemente




01




Einstellung Zeit

- 1 Krone in Position III herausziehen (Uhr bleibt stehen).
- 2 Krone drehen bis die aktuelle Zeit 08:45 angezeigt wird.
- 3 Krone zurück in Position I drücken.

Hinweis
* Um die Zeit «sekundengenau» einzustellen, muss 1 bei der Sekundenzweigerstellung «60» gezogen werden.
Nach der Einstellung des Stunden- und Minutenzeigers muss 2 «sekundengenau» in Pos. I zurückgedrückt werden.




02




Schnellkorrektur Datum

- 1 Krone in Position II herausziehen (Uhr läuft weiter).
- 2 Krone drehen bis das aktuelle Datum 17 erscheint.
- 3 Krone zurück in Position I drücken.

Hinweis
In der Kalenderschaltphase von ca. 21:00 bis 24:00 Uhr muss das Datum des folgenden Tages eingestellt werden.
Extreme Beschleunigung in der Schnellkorrektur kann zu einer falschen Datumsanzeige führen. Durch Schalten des Datums von 01 bis 31 (Krone Position II) wird die Synchronisation wieder hergestellt.



03




Einstellung Datum und Uhrzeit


Beispiel:
– Datum/Uhrzeit auf der Uhr: 17 / 01:25
– Aktuelles Datum/Uhrzeit: 4 / 20:30

- 1 Krone in Position II herausziehen (Uhr läuft weiter).
- 2 Krone drehen bis der Vortag des aktuellen Datums erscheint 3.
- 3 Krone in Position III herausziehen (Uhr bleibt stehen).
- 4 Krone drehen bis das aktuelle Datum 4 erscheint.
- 5** Krone weiter drehen bis die aktuelle Zeit 20:30 angezeigt wird.
- 6 Krone zurück in Position I drücken.

Hinweis
* «sekundengenau» Zeiteinstellung: Siehe Hinweis im Kapitel «Einstellung Zeit»
**24-Stundenrhythmus beachten.



04




Chronograph: Grundfunktion

(Start / Stopp / Nullstellung)

Beispiel:

- 1 Start: Drücker A drücken.
- 2 Stopp: Um die Zeitmessung abzubrechen, Drücker A nochmals drücken und die Chronographenzähler ablesen:
4h / 20 Min. / 38 Sek.
- 3 Nullstellung: Drücker B drücken. (Die Chronographenzähler werden in ihre Nullstellungen zurückgestellt.)

05




Chronograph: Aufaddierte Zeitmessung

Beispiel:

- 1 Start: (Zeitmessung starten)
- 2 Stopp: (z.B. 15 Min. 5 Sek. nach 1)
- 3 Restart: (Zeitmessung wieder freigeben)
- 4 Stopp: (z.B. 5 Min. 12 Sek. nach 3) = 20 Min. 17 Sek. (Aufaddierte Messzeit wird angezeigt)
- 5 Nullstellung: Die Chronographenzähler werden in ihre Nullpositionen zurückgestellt.

Hinweis
* Nach 4 kann die Aufaddierung der Zeitmessung fortgesetzt werden. Dies über Drücker A (Restart / Stopp, Restart / Stopp, ...).

06




Chronograph: Zwischenzeitmessung

Beispiel:

- 1 Start: (Messzeit starten)
- 2 Zwischenzeit anzeigen: z.B. 20 Minuten 17 Sekunden (die Zeitmessung läuft im Hintergrund weiter)
- 3 Messzeit aufrollen: (Die Chronographenzähler werden im Schnelllauf auf die weitergelaufene Messzeit nachgeführt.)
- 4 Stopp: (Endzeit wird angezeigt)
- 5 Nullstellung: Die Chronographenzähler werden in ihre Nullpositionen zurückgestellt.

Hinweis
* Nach 4 können weitere Zwischenzeiten angezeigt werden. Dies über Drücker B (Zwischenzeit anzeigen / Messzeit aufrollen, ...).


07



Ausrichtung des Chronographenzeigers auf Nullposition

Beispiel:
Einer oder mehrere Chronographenzeiger sind nicht in ihren korrekten Nullpositionen und müssen ausgerichtet werden (z.B. nach Batteriewechsel).

- 1 Krone in Position III herausziehen. (Alle Chronographenzeiger stellen sich in ihre korrekte bzw. nicht korrekte Nullposition.)
- 2 Drücker A und B gleichzeitig während mindestens 2 Sekunden drücken. (Der Sekundenzählerzeiger dreht um 360° → Korrekturmodus ist aktiviert.)



Ausrichtung des Sekundenzählerzeigers

Einzelschritt: A 1 x kurz
Kontinuierlich: A lang

Nächsten Zeiger ausrichten B

Einzelschritt: A 1 x kurz
Kontinuierlich: A lang


- 3 Krone in Position I zurückdrücken. Abschluss der Chronographenzeiger-Ausrichtung (dies ist jederzeit möglich).

08

You have decided to buy a watch, which was assembled by a watchmaker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda Brand.

In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.

Description of the display and control buttons



01

Setting the time

- 1 Pull out the crown to position III (the watch stops).
- 2 Turn the crown until you reach the correct time 8:45.
- 3 Push the crown back into position I.

Please note:
* In order to set the time to the exact second, 1 must be pulled out when the second hand is in position «60». Once the hour and minute hands have been set, 3 must be pushed back into position I at the exact second.

02

Setting the date (quick mode)

- 1 Pull out the crown to position II (the watch continues to run).
- 2 Turn the crown until the correct date 11 appears.
- 3 Push the crown back into position I.

Please note:
During the date changing phase between approx. 9 PM and 12 PM, the date must be set to the date of the following day.
An extreme acceleration in setting the date with quick mode can induce a false date indication. The synchronization is re-established by setting the date from 01 till 31 (crown in position II).

03

Setting the date/time

- 1 Pull out the crown to position II (the watch continues to run).
- 2 Turn the crown until yesterday's date appears 3.
- 3 Pull out the crown to position III (the watch stops).
- 4 Turn the crown until the correct date 4 appears.
- 5 Continue to turn the crown until the correct time 8:30 PM appears.
- 6 Push the crown back into position I.

Please note:
* To set your watch to the exact second, please refer to the chapter entitled «setting the time».
** Please observe the AM/PM clock rhythm.

04

Chronograph: Basic function

(Start / Stop / Reset)

Example:

- 1 Start: Press push-button A.
- 2 Stop: to stop the timing, press push-button A once more and read the chronograph counters: 4h / 20 min / 38 sec.
- 3 Zero positioning: Press push-button B. (The chronograph hands will be reset to their zero positions.)

05

Chronograph: Accumulated timing

Example:

- 1 Start: (start timing)
- 2 Stop: (e.g. 15 min 5 sec following 1)
- 3 Restart: (timing is resumed)
- 4 Stop: (e.g. 5 min 12 sec following 3 = 20 min 17 sec (The accumulated measured time is shown))
- 5 Reset: The chronograph hands are returned to their zero positions.

Please note:
* Following 4, the accumulation of the timing can be continued by pressing push-button A (Restart / Stop, Restart / Stop, ...).

06

Chronograph: Intermediate or interval timing

Example:

- 1 Start: (start timing)
- 2 Display interval: e.g. 20 minutes 17 seconds (timing continues in the background)
- 3 Making up the measured time: (The chronograph hands are quickly advanced to the ongoing measured time.)
- 4 Stop: (Final time is displayed)
- 5 Reset: The chronograph hands are returned to their zero position

Please note:
* Following 2, further intervals or intermediates can be displayed by pressing push-button B (display interval / make up measured time, ...).

07

Adjusting the chronograph hands to zero position

Example:

One or several chronograph hands are not in their correct zero positions and have to be adjusted (e.g. following a battery change).

- 1 Pull out the crown to position III (all chronograph hands are in their correct or incorrect zero position).
- 2 Keep push-buttons A and B depressed simultaneously for at least 2 seconds (the second counter hand rotates by 360° → corrective mode is activated).

Adjusting the second counter hand
Single step: A 1 x short
Continuous: A long

Adjusting the next hand B

Adjusting the minute counter hand and the hour counter hand (mechanical coupled)
Single step: A 1 x short
Continuous: A long

- 3 Returning the crown to position I
Termination of the chronograph hands adjustment (can be carried out at any time).

08

